

# SLV-373/373UB/373VP

## RMT-V373

## SERVICE MANUAL

*AEP Model*  
SLV-373

*UK Model*  
SLV-373UB

*West Germany Model*  
SLV-373VP



Remote commander RMT-V373 is available as a unit, but as individual parts the battery case lid of commander is only available.

Photo: SLV-373VP

For MECHANICAL ADJUSTMENTS, refer to the "VHS MECHANICAL ADJUSTMENT MANUAL II" (9-972-816-11)

● See Supplement-1 for Adjustments.

### SPECIFICATIONS

#### System

<b>Format</b>	VHS PAL standard
<b>Video recording system</b>	Rotary two-head helical scanning FM system
<b>Video signal</b>	PAL colour (System B and G: SLV-373/373VP, System I: SLV-373UB/373EI) DDR SECAM colour (SLV-373VP) CCIR monochrome signals 625 lines
<b>Tape speed</b>	SP: 23.39 mm/sec. LP: 11.70 mm/sec.
<b>Maximum recording/playback time</b>	SP: 4 hours (with E-240) LP: 8 hours (with E-240)
<b>Fast-forward/rewind time</b>	Approx. 3 min. 20 sec. (with E-180)
<b>High speed rewind time</b>	Approx. 2 min. 20 sec. (with E-180)

#### Tuner Section

<b>Tuner system (audio)</b>	Intercarrier system
<b>Channel coverage</b>	SLV-373/373VP VHF channels E2 — E12 (A to H only for Italy) CATV channels S01 — S03 CATV channels S1 — S20 HYPER S21 — S41 UHF channels E21 — E69
	SLV-373UB UHF channels B21 — B68
	SLV-373EI VHF channels A — J UHF channels E21 — E69
<b>RF output signal</b>	SLV-373/373VP/373EI UHF channels E30 — E39 (adjustable)
	SLV-373UB UHF channels B30 — B39 (adjustable)
<b>Aerial out</b>	75-ohms asymmetrical aerial socket

— Continued on page 2 —



VHS VIDEO CASSETTE RECORDER  
**SONY**®

## Inputs and Outputs

<b>Video inputs</b>	LINE 2: phono jacks EURO-AV: 21-pin (pin 20) 1 Vp-p, 75 ohms, unbalanced, sync negative
<b>Audio inputs</b>	LINE 2: phono jacks 47 kilohms, -7.5 dBs (0 dBs = 0.775 V rms) EURO-AV: 21-pin (pins 2 and 6) More than 10 kilohms, -4 dBs
<b>Video output</b>	EURO-AV: 21-pin (pin 19) 1 Vp-p, 75 ohms, unbalanced, sync negative
<b>Audio output</b>	EURO-AV: 21-pin (pins 1 and 3) Output impedance: less than 1 kilohm -4 dBs with 10 kilohms load
<b>CONTROL S IN</b>	Minijack (1)

## Timer Section

<b>Clock</b>	Quartz locked
<b>Time indication</b>	24-hour cycle
<b>Timer setting</b>	Only for recording 8 programmes in one month at max.
<b>Timer back-up</b>	Built-in self-charging capacitor Back-up duration: Up to an hour at one time

## General

<b>Power requirements</b>	240 V AC, 50 Hz (SLV-373UB) 220 V AC, 50 Hz (SLV-373/373VP/373EI)
<b>Power consumption</b>	25 W
<b>Operating temperature</b>	5°C to 40°C (41°F to 104°F)
<b>Storage temperature</b>	-20°C to 60°C (-4°F to 140°F)
<b>Dimensions</b>	430 × 87 × 358 mm (w/h/d) (17 × 3 3/8 × 14 1/4 inches)
<b>Weight</b>	5.7 kg (12 lb 9 oz)

## Wireless Commander RMT-V373

<b>Remote control system</b>	Infrared control
<b>Command mode</b>	VTR 1/2/3
<b>Power requirements</b>	3 V DC, two IEC designation R6 batteries
<b>Dimensions</b>	75 × 45 × 235 mm (w/h/d) (3 × 1 3/4 × 9 1/4 inches)
<b>Weight</b>	220 g (8 oz) excluding batteries

## Accessories Supplied

Wireless Remote Commander RMT-V373 with two R6 batteries	(1)
75-ohm coaxial cable	(1)
Screwdriver	(1)
AC power cord	(1)

Design and specifications are subject to change without notice.

### Note


This appliance conforms with EEC Directive 87/308/EEC regarding interference suppression.

## SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the B+ voltage to see it is at the values specified.

### SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY. CIRCUIT ADJUSTMENTS THAT ARE CRITICAL TO SAFE OPERATION ARE IDENTIFIED IN THIS MANUAL. FOLLOW THESE PROCEDURES WHENEVER CRITICAL COMPONENTS ARE REPLACED OR IMPROPER OPERATION IS SUSPECTED.


## TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>1. GENERAL</b>			<b>4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS</b>		
	Identifying the Operational Parts.....	4	4-1.	Frame Schematic Diagram.....	30
	Remote Control Operation.....	7	4-2.	Printed Wiring Boards and Schematic Diagram.....	32
	Date and Clock Setting.....	8		· RP-100 Board.....	32
	Adjust the TV About the MENU Display.....	9		· YC-90 Board.....	37
	Presetting the Active Channels.....	11		· MA-60 Board.....	43
	Playback.....	13		· MD-40 Board.....	57
	Use of the Tape Counter.....	16		· MF-95, MF-96, MF-97 Boards.....	64
	Timer Activated recording.....	17		· CA-42 Board.....	71
	Quick Timer Recording.....	22		· Power Supply Board.....	77
	Index Function.....	23	4-3.	Semiconductor Lead Layouts.....	81
	Indications in the Display Window.....	25	<b>5. EXPLODED VIEWS</b>		
<b>2. DISASSEMBLY</b>			5-1.	Front Panel, Cabinet Assemblies.....	82
2-1.	Upper Case, Front Panel Assy.....	26	5-2.	Chassis Assembly.....	83
2-2.	MF-95, MF-96 and MF-97 Boards.....	26	5-3.	FL Cassette Compartment.....	84
2-3.	RP-100 Board.....	26	5-4.	Mechanism Deck 1.....	85
2-4.	Bottom Plate, MA-60 Board.....	27	5-5.	Mechanism Deck 2.....	86
2-5.	Power Block.....	27	5-6.	Mechanism Deck 3.....	87
2-6.	Cassette Compartment Assy and Mechanism Deck Assy.....	27	<b>6. ELECTRICAL PARTS LIST</b>		
2-7.	YC-90 and CA-42 Boards.....	27	HARDWARE LIST.....		
2-8.	Internal Views.....	28	101		
<b>3. DIAGRAMS</b>			<b>7. MECHANICAL ADJUSTMENT</b>		
3-1.	Circuit Boards Location.....	29	102		

# SECTION 1 GENERAL

This section is extracted from instruction manual.


## Identifying the Operational Parts



### Front

- (1) ON/STANDBY switch and indicator
- (2) **EJECT** button  
Press to eject the cassette. This button does not function during recording.
- (3) Cassette compartment
- (4) Display window and function mode display  
See "Indications in the Display Window." (page 58)
- (5) DUAL MODE SHUTTLE ring
 


In the stop mode	Turn the ring clockwise (▶▶) to advance the tape rapidly, and counterclockwise (◀◀) to rewind the tape.
In the playback mode	Turn the ring clockwise (FORWARD) to advance and counterclockwise (REVERSE) to reverse the picture in various speeds including a still picture when the ring is released.
- (6) ▶ **PLAY** button
- (7) REMOTE Sensor  
Point the Commander here.
- (8) ▼ **OPEN**  
Press to open the front panel.
- (9) || **PAUSE/STILL** button  
In the playback mode: Press to obtain a still picture.  
In the recording mode: Press to pause.
- (10) ■ **STOP** button



### Front


- (11) LINE IN 2 VIDEO/AUDIO jacks (phone type)  
Connect to the video/audio output jacks of another VTR or a video camera recorder.
- (12) SHARPNESS SOFT/SHARP control  
Use to adjust the sharpness of the picture if necessary. Normally set this control at the center position.
- (13) COMMAND MODE VTR 1/2/3 selector (page 15)  
Set to the same position as the COMMAND MODE switch on the Commander.
- (14) VPS (Video Programme System) ON/OFF switch (SLV-373VP only) (page 47)
- (15) TV/VTR button  
Press and light the VTR indicator in the display window to view the playback of the VTR or a programme selected on the VTR. Press this button again to turn off the VTR indicator to view a programme selected on the TV. This button is effective only when the VTR is connected to the TV via EURO AV.
- (16) INPUT SELECT switch  
Press to select the signals to be recorded by the VTR. The selected mode will be indicated in the display window as follows:  
TUNER: To record TV programmes.  
LINE L1: To record the signals from equipment connected to the EURO AV.  
LINE L2: To record the signals from equipment connected to the LINE IN 2 jacks.
- (17) REC MODE (SP/LP) button  
Press to select the recording tape speed SP or LP.

## Identifying the Operational Parts



### Front


- 18 EDIT ON/OFF button (page 55)  
Set to ON during editing to obtain a high quality picture.
- 19 TIMER REC ON/OFF button  
Press this button to enter the timer recording standby mode. Press it again to release the timer recording standby mode before changing or cancelling a timer recording or to operate the unit before a timer recording starts.
- 20 QUICK TIMER button (page 49)  
Press to activate the quick timer recording function.
- 21 <<< HIGH SPEED REWIND button
- 22 PROGRAM +/- buttons  
Press to select the programme positions.
- 23 TRACKING NORMAL/SLOW and STILL ADJUST  $\nabla/\Delta$  buttons (page 27)  
Press to clear streaks if they appear on the screen in the normal and slow playback. (Manual tracking adjustment)  
Press to reduce picture shaking in the still mode. (Still adjustment)
- 24 TRACKING AUTO/MANUAL button (page 27)  
Press to reactivate the automatic tracking function after manual tracking adjustment.
- 25 ● REC (record) button (page 33)




### Rear




- 1 RF CHANNEL screw (30 to 39) (page 18)
- 2 AERIAL OUT socket (page 13)
- 3 EURO-AV (21-pin) (page 13)
- 4 CONTROL S IN jack (mini type) (page 55)  
Connect to the CONTROL S output jack of other SONY products for systematic operations such as synchronized editing
- 5 AC INPUT  
Connect the supplied AC power cord
- 6 DX/LOCAL switch  
Normally set to DX. If the TV signal is very strong, set it to LOCAL with the supplied screwdriver.
- 7 AERIAL IN socket (page 13)

## Identifying the Operational Parts





### Remote Commander RMT-V373

- The buttons on the Commander with the same name or mark as those on the unit have the same function.
- The buttons with a red dot can be used to remotely control Sony TVs with the  mark when the TV/VTR remote control selector is set to TV. However, the TV/VTR button and/or the - / - - (10's digit) button cannot operate certain Sony's TVs.


- [1] TIMER REC (ON/OFF) button
- [2] TIMER REC CHECK/CLEAR buttons (page 43)  
Press to check, correct, or clear the timer settings.
- [3] Liquid-crystal display
- [4] TV | VTR | remote control selector (page 15)  
Set to  to control this VTR and set to  to control the TV.
- [5]  (on/standby) button  
To turn on the TV from the standby mode, press one of the programme position number buttons.
- [6] Timer recording/clock set buttons (page 16, 39)
  - TIMER SET
  - DAY
  - TUNN ON time
  - TUNN OFF time
  - PROG (programme position) + / -
  - TRANSMIT

- You can use the PROG + / - buttons to select the programme positions during VTR or TV operation as well as in the timer setting procedure



- [7] MEMORY button (page 46)
- [8] CLOCK SET (SET/START) button (page 16)
- [9] REC MODE select button (page 33)
- [10] Programme position number buttons  
Press to select the programme position directly
- [11] - / - - (10's digit) button  
Press to select a programme number over 9. To select 23, press - / - -, then 2 and 3
- [12] DATA SCREEN button (page 30)
- [13] TIMER ON SCREEN button  
Press to display the timer settings
- [14] COMMAND MODE button (page 15)
- [15] TV/VTR button (page 35)
- [16] VOL (TV volume) + / - buttons  
Press to control the volume of the TV. Effective only for Sony TVs with the  mark.
- [17] INDEX button (page 52, 53, 54)
- [18] INPUT SELECT button  
Press to select the source to be recorded. The selected input mode indicator will appear in the display window
- [19] COUNTER RESET button (page 36)

## Identifying the Operational Parts



**20** INDEX MARK and ERASE buttons  
(page 51, 54)

**21** Tape transport buttons (page 26, 28)

- PAUSE
- REC (recording) buttons
- ▷ PLAY
- ◀◀ HIGH SPEED REWIND
- ⊖/⊕ SEARCH (reverse/forward)
- ◀ REW (rewind)
- ▶ FF (fast forward)
- STOP

**22** Menu operation buttons

Press MENU to display or erase the main MENU. Press EXECUTE to store the selected parameters. Press ▲/▼/◀/▶ to move the cursor.

**23** Playback direction set, frame-by-frame, still and SLOW +/- buttons (page 28)

Press ■ for a still picture.

Press < ◀/▶ > to select the direction for frame-by-frame picture.

Press < ◀/▶ > to select the direction for any playback mode.

Press SLOW +/- for slow playback between 1/5 to 1/30 times normal speed. Press + or - to change the playback speed.


**24** SWING SHUTTLE dial (page 29)

Turn and hold it at the position where the desired playback speed is obtained. You can select slow (1/5), normal (1), double (×2) or continuous scan speed (⊖ or ⊕) from any playback mode. Turn the dial clockwise for forward playback, or counterclockwise for reverse playback.


When the dial is released, it will return to the still picture position automatically. To resume normal playback, press ▷.

## Remote Control Operation

1



2




### Preparing the Commander

#### ■ Battery Insertion

- 1 Slide and remove the cover.
- 2 Insert two R6 (size AA) batteries with polarity positioned correctly.
- 3 Close the cover. Set the date and clock referring to the "Date and Clock Setting."

**Note on batteries**  
With normal operation, batteries will last for about six months. However, if the Commander will not be used for a long period, remove the batteries to avoid possible damage from battery leakage.



### Command Mode Setting

Set the COMMAND MODE 1/2/3 selector on the unit to the same number displayed in the LCD display. To change the setting on the Commander, press COMMAND MODE repeatedly. Then, set the [TV]/[VTR] remote control selector to [VTR].

### Remotely Controlling Other Sony Equipment


#### ■ Controlling another VTR equipped with a command mode selector

Set different command modes for this VTR (VTR 3, for instance) and the other VTR (VTR 1). Select VTR 1 on the Commander to control the other VTR and VTR 3 to control this VTR.

#### ■ Controlling equipment without a command mode selector

Change the setting on the Commander as follows to control each type of VTR:  
 VTR 1: Sony Betamax infrared remote control VTRs  
 VTR 2: Sony 8 mm format VTRs  
 VTR 3: Sony VHS format VTRs

## Date and Clock Setting



### Before You Begin

The time and date between the years 1990 and 2005 can be set with the Commander.


### Operation

Example: To set to 15:30, Tuesday, November 27, 1990.

- 1 Press CLOCK SET.
- 2 Keep pressing the D (date) button until 11 M 00 Y is displayed. The date will be incremented slowly up to 30 days ahead and then the month will be incremented.
- 3 Press the + side or - side of the D (date) button until 27 D is displayed. The day of the week appears automatically.
- 4 Press the H (hour) and M (minute) buttons under TURN OFF to set the current time.
- 5 Point the Commander at the VTR and press TRANSMIT. A beep sound confirms that the date and clock setting is registered in the VTR as well.
- 6 Check the display window on the unit and press CLOCK SET.


When 0:00 is blinking on the unit. Any time power is interrupted for more than an hour, you will see 0:00 blinking when power is restored. You will have to re-set the date and clock again.

When a short beep sounds repeatedly. The VTR is in the timer recording or quick timer recording modes or standby mode for timer recording and the setting cannot be transmitted.





## Adjusting the TV



### Before You Begin


If you have connected your VTR and TV using only the aerial sockets, one of the television programme positions must be adjusted to receive the VTR's playback signal. If TV/VTR connection is made via the EURO-AV, skip this step.

### Operation

- 1 Make connections referring to "Connections" and press ON/STANDBY.
- 2 Press INPUT SELECT to light LINE L2 in the display window. Do not connect any equipment to the LINE IN 2 VIDEO jack.
- 3 Turn on the TV and select a programme position that is not used to receive a TV station.
- 4 Tune the TV so that a blue screen with tape counter and tape speed indication is clearly displayed on the TV screen.
- 5 Press INPUT SELECT to light TUNER in the display window.
- 6 Press the PROGRAM +/- on the VTR and check that the screen changes to a different programme.

Now your TV is tuned to receive the VTR's playback picture. Whenever playing back a tape, select the programme position you chose in step 3. If you are not sure how to tune your TV, refer to the TV's instruction manual or consult your dealer.




## Adjusting the TV



### When the Playback Picture is not Free of Disturbance

- 1 Select a programme position on the TV between UHF channels 30 and 39, so that the TV shows no picture and a steady rustling sound or no sound is heard.
- 2 Press INPUT SELECT to light LINE L2 in the display window. Do not connect any equipment to the LINE IN 2 VIDEO jack.
- 3 Turn the RF CHANNEL screw with the supplied screwdriver so that a blue screen with tape counter and tape speed indication is clearly displayed on the TV screen.
- 4 Press INPUT SELECT to light TUNER in the display window.
- 5 Press the PROGRAM +/- on the VTR and check that the screen changes to a different programme.

## About the MENU Display



This VTR is equipped with a menu display function. Menu display enables you to perform certain operations which are displayed on the TV or the monitor.




First display the main MENU, and select the item to be operated or preset.

### How to Display the main MENU

#### ■ Before you begin

Check the connections between the VTR and the TV.

#### ■ Operation

- 1 Turn on the TV.  
Set to the programme position for the VTR if VTR-TV connection is made via the serial sockets. Select VTR input if VTR-TV connection is made via the EURO-AV.
- 2 Press .
- 3 Press MENU.  
The main MENU will appear on the screen.
- 4 Move cursor to the desired menu by  or .
- 5 Press EXECUTE.  
The selected menu will appear on the screen.

To erase the main MENU display  
Press MENU again.

- To display other menu displays
- 1 Press MENU to erase the present display.
  - 2 Press MENU again to display main MENU.
  - 3 Move cursor to the desired menu
  - 4 Press EXECUTE.

## About the MENU Display

### Details of Each Menu

Here is a list of the menus in the main MENU. For details, refer to the sections indicated.

#### ■ AUTO MENU

Use to select an automatic tape operation. See "Assigning a Desired Operation Mode" (page 31).

#### ■ MODE SET

Use to select the following mode settings:

**TIMER REC-REW ON/OFF**  
(See "Timer Activated recording" on page 44)

**BUZZER ON/OFF**  
(See "Timer Activated Recording" on page 41)

**DIMMER ON/OFF**  
Select ON to dim out the indications in the display window.



**BACK COLOUR BL/GR/PK**  
Select your favourite back colour of the on-screen display from BL (blue), GR (green) and PK (pink).  
Back colour is set to BL at the time of shipment.

#### ■ TUNER PRESET

Use to preset the active channels in your area. See "Presetting the Active Channels" (page 21).

**Note**  
The position of the cursor is retained as long as the power cord is connected.

## Presetting the Active Channels



### Before You Begin


- This VTR is capable of receiving VHF channels E2-E12, UHF channels E21-E69, and cable TV channels S1-S41 and S01-S03.
- The receivable channels are governed by the TV broadcasting system in your area
- Up to 60 channels can be allocated to any desired programme position.

### To Call Up the TUNER PRESET Menu

- 1 Turn on the VTR and press INPUT SELECT to light the TUNER indicator and the programme position number in the display window.
- 2 Turn on the TV. Set to the programme position for the VTR if VTR-TV connection is made via the aerial sockets. Select VTR input if VTR-TV connection is made via the EURO-AV.
- 3 Press MENU with the VTR in the stop mode. The main MENU appears.
- 4 Move cursor with ▲ or ▼ to TUNER PRESET.
- 5 Press EXECUTE. The TUNER PRESET menu appears.

Note for the users of SLV-373UB  
 The TUNER PRESET menu of the SLV-373UB does not have the NORMAL/CATV selection as illustrated.

## Presetting the Active Channels




### Tuning a Desired Channel

- 1 Call up the TUNER PRESET menu.
- 2 Move cursor to NORMAL/CATV with ▲ and select NORM with ◀ or ▶. (For SLV-373UB, skip this step.) To tune-in CATV channels first, select CATV.
- 3 Select the desired programme position by pressing PROG + / - on the Commander or PROGRAM + / - on the unit.
- 4 Move cursor to CHANNEL SET with ▲ or ▼ and press ◀ or ▶. The channel number automatically increases with ▶ and decreases with ◀. The number stops changing when the first channel received in your area is detected and the screen returns to the blue background 5 seconds after.
- 5 To allocate a channel to the next programme position, repeat steps 2 to 4.
- 6 Press EXECUTE to store the allocated channels and return to original screen.

Channel scanning on your VTR  
 • When ▶ is pressed in steps 4 and 5, the channels are scanned in the following order. When ◀ is pressed the scanning order is reversed.  
 VHF (E2-E12) → UHF (E21-E69) → CATV (S1-S20) → HYPER BAND (S21-S41) → CATV (S01-S03).  
 • The SLV-373UB only scans UHF channels B21 to B68.  
 • In Italy, channel numbers 13 to 20 correspond to channels A to H.

## Presetting the Active Channels



### Erasing Unwanted Programme Positions


The VTR can be preset so that only the desired programme positions will appear when you press PROG +1- or PROGRAM +1-.

- 1 Call up the TUNER PRESET menu.
- 2 Press PROG +1- on the Commander or PROGRAM +1- on the unit to call up the unused programme position.
- 3 Press 0 twice or keep pressing < or > until 0 is displayed.
- 4 Repeat steps 2 and 3 to erase other programme positions.
- 5 Press EXECUTE.

■ To enter the erased programme positions again  
Follow the operations in "Tuning a Desired Channel."

### To Allocate the Channels Directly


After step 3 in "Tuning a Desired Channel," move cursor to CHANNEL SET. Enter the desired programme numbers using the programme position number buttons. To enter one's digits, press 0 and then the desired number. To enter two digit numbers, press the ten's digit number and then the one's digit number.




### Manually Fine-tuning a Weak Station

Normally the AFT (Automatic Fine Tuning) function fine-tunes the picture with the AFT in the TUNER PRESET menu set to ON. (The AFT indicator lights in the display window.) However, when the programme received on the VTR is distorted due to signal interference, manual fine tuning may solve the problem.

- 1 Select the distorted programme position by pressing PROG +1- on the Commander or PROGRAM +1- on the unit.
- 2 Call up the TUNER PRESET menu.
- 3 Move cursor to FINE TUNING. The line tuning meter appears.
- 4 Press < or > to obtain the best picture. When < or > is pressed, the dot will move to AFT OFF automatically and the AFT indicator in the display window will be turned off.
- 5 Press EXECUTE to store that position and return to the original screen.





**Playing a Tape**

- 1 Turn on the TV and select the programme position for the VTR. If VTR TV connection is made via EUHO-AV, select the input for the VTR.
- 2 Insert a cassette. The VTR will be turned on. If your cassette has its safety tab removed, playback starts automatically.
- 3 Press  $\triangleright$ . Playback starts. The VTR automatically rewinds the tape when it reaches the end.

**To stop playback**  
Press  $\blacksquare$  STOP.

**To advance the tape rapidly**  
Turn the DUAL MODE SHUTTLE ring clockwise ( $\triangleright$ ), or press  $\triangleright$  FF on the Commander during stop mode.




**To rewind the tape**  
Turn the DUAL MODE SHUTTLE ring counterclockwise ( $\triangleleft$ ), or press  $\triangleleft$  REW on the Commander during stop mode.

**To rewind the tape at high speed**  
Press  $\triangleleft\triangleleft$  HIGH SPEED REWIND.

**To get a sharper picture**  
Turn the SHARPNESS control toward SHARP.

**To get a softer picture**  
Turn the SHARPNESS control toward SOFT.

**When the tape is played back to the end**  
The tape will be automatically rewound to the beginning (auto rewind). The power will remain on.



**Picture Adjustments**

**Auto tracking function**

The tracking condition is automatically adjusted on this VTR. The AUTO TRACKING indicator blinks while the VTR is searching for the best tracking condition and lights when maximum playback picture is obtained. The automatic tracking control is activated in the following conditions:

- when the cassette is inserted and played back.
- when the recording mode on the playback tape is switched between SP and LP.
- when the picture is distorted by scratches etc. on the tape.
- when the AUTO TRACKING indicator is turned on by pressing TRACKING AUTO/MANUAL after the picture is adjusted manually. (See below.)

**Manual adjustment during normal playback**

If streaks or snow appear, adjust the picture using the TRACKING NORMAL/SLOW and STILL ADJUST  $\nabla/\Delta$ .



Press either  $\nabla$  or  $\Delta$  to obtain the best possible picture.

The tracking meter will appear on the TV screen and the AUTO TRACKING indicator will be turned off.

**Notes on Automatic Tracking**





- When the manual adjustment proves unsatisfactory, press both of the TRACKING NORMAL/SLOW and STILL ADJUST  $\nabla/\Delta$ . The tracking condition will return to the center position.
- Tracking adjustment may not be possible when the recording condition of the tape is very poor.

# Playback



## Various Playback Modes

- **To obtain a still picture**  
 During playback mode press **⏸ PAUSE/STILL** on the unit or **⏸ PAUSE** or **⏸** on the Commander. To resume normal playback, press **▶ PLAY**, **⏸ PAUSE/STILL**, or **⏸ PAUSE**. When the pause mode lasts for more than 5 minutes, the unit will re-enter the playback mode automatically.
- **To search for a particular scene — Picture search**  
 During playback mode, press **◀ REW** or **▶ FF**. While the button is pressed, a high speed picture without sound will appear on the TV screen. When the button is released, the unit will return to the previous mode.
- **To watch the picture during fast-forward or rewind mode — Locked picture search**  
 During the playback mode, press **SEARCH** or **SEARCH** on the Commander. A high speed picture in forward or reverse will appear on the screen even when the button is released. To resume normal playback, press **▶ PLAY**.
- **To watch slow motion playback**  
 During playback or still mode, press **▶ SLOW** on the Commander. Change the slow motion speed with the **+** or **-** buttons. Press **+** to increase the playback speed, and **-** to decrease the playback speed.
- **To see the picture momentarily while the unit is in the fast-forward or rewind mode without picture on the TV screen**  
 During fast-forward, turn the **DUAL MODE SHUTTLE** ring clockwise (**▶▶**) or press **▶▶ FF** on the Commander. During rewind, turn the **DUAL MODE SHUTTLE** ring counterclockwise (**◀◀**) or press **◀◀ REW** on the Commander. The high speed playback picture can be seen as long as the ring is held in that position, or the button is pressed. Release the ring or button to return to the previous mode.
- **To watch a frame-by-frame picture**  
 During still mode, press **▶▶** to advance the picture one frame. Press **◀◀** to reverse the picture one frame. Each press of **▶▶** / **◀◀** will move the picture one frame. Press **▶ PLAY** to resume normal playback.



- **To watch reverse direction playback, and slow picture**  
 During forward playback of the desired mode, press **<** on the Commander. Press **▶ PLAY** or **>** to resume forward playback.



To eliminate streaks or noise bands during slow motion play  
 Adjust the picture with **TRACKING NORMAL/SLOW** and **STILL ADJUST ▼/▲** inside the front panel. The picture can be adjusted easily in faster speed playback.

To eliminate the bands on the top or bottom of the screen in still mode  
 Change to the slow motion play mode and adjust the picture with **TRACKING NORMAL/SLOW** and **STILL ADJUST ▼/▲**.

To eliminate picture shaking during still mode  
 Adjust the picture with **TRACKING NORMAL/SLOW** and **STILL ADJUST ▼/▲** inside the front panel.

Notes on picture search  
 The picture may turn to a monochrome picture during picture search when playing back tapes recorded in LP mode depending upon the condition of the connected TV.

- **To enjoy various playback modes by the DUAL MODE SHUTTLE ring or the SWING SHUTTLE dial**  
 Various playback modes as illustrated can be selected with **DUAL MODE SHUTTLE** ring on the unit or the **SWING SHUTTLE** dial on the Commander from any playback mode. The same speed is available in the reverse direction. Turn the ring or the dial and hold it at the position where the desired playback speed is obtained. When you release the ring or the dial, the picture will freeze. To resume normal playback, press **▶ PLAY**.



**Data Screen**


Data screen information illustrated on the left will automatically appear on the screen during playback or recording as a reference. Note, however, that the data screen will not be displayed when the VTR is in slow motion or playback pause mode.

■ To erase or display the data screen  
Press DATA SCREEN.


**Notes on the remaining tape length indicator**

- The remaining tape length indicator only shows the approximate amount of tape left.
- The indication may shift vertically during the fast-forward or rewind mode.
- It may not operate properly when a short tape, such as the E-30 and VHS-C type cassette, or when a non-standardized tape is inserted.


—15—




1



2



3



**Assigning a Desired Operation Mode**

Guided by the AUTO MENU, you can make the VTR enter the desired operational sequence automatically.

- 1 Press MENU while the VTR is in the stop mode.  
The main MENU appears.
- 2 Move cursor with ▲ or ▼ to AUTO MENU and press EXECUTE.  
The AUTO MENU appears.
- 3 Move cursor with ▲ or ▼ to the desired operational sequence and press EXECUTE.  
The selected operation will begin.

The selected operating mode will be superimposed on the TV screen for a few seconds. The AUTO indicator will light in the display window during AUTO MENU operation.


**Notes on AUTO MENU operation**  
AUTO MENU cannot be operated if there is no cassette installed or if the VTR is in modes other than stop mode. A short beep alerts you if the AUTO MENU is not operable.

**Note on "GO TO REC START-PLAY"**

The recording start point data will be erased from the memory after the following operations and "GO TO REC START-PLAY" will not be operable.


- When COUNTER RESET is pressed
- When cassette is ejected and re-inserted
- When HIGH SPEED REWIND is pressed.

## Use of the Tape Counter



### Understanding Counter Zero Position


The tape counter on this VTR can be used as a reference when you wish to locate a certain scene after recording or playback. Press COUNTER RESET to set the counter to "0H00M00S" (counter zero position) before operation. The VTR will keep counting the length of tape being played back or recorded. Note, however, that the tape counter will not count the portions of tape with no signals recorded. This VTR automatically resets the counter to zero whenever a cassette is inserted. Two additional features using COUNTER RESET are available on this VTR.



### Tape Return

The VTR can search for the counter zero position and stop. This function is useful for locating a particular scene after recording or playback.

- 1 Press COUNTER RESET at the desired scene during recording or playback.
- 2 Press  $\blacksquare$  to stop recording or playback.
- 3 Press MENU and select AUTO MENU. See "Assigning a Desired Operation Mode" for operation.
- 4 Move cursor to "GO TO ZERO-STOP."
- 5 Press EXECUTE.



#### AUTO MENU

PLAY-REW-POWER OFF  
 ▶ GO TO ZERO-STOP  
 GO TO ZERO-PLAY  
 GO TO REC-START-PLAY  
 REW-POWER OFF  
 REW-EJECT-POWER OFF  
 REW-PLAY  
 REW-TIMER REC

#### AUTO MENU

PLAY-REW-POWER OFF  
 GO TO ZERO-STOP  
 ▶ GO TO ZERO-PLAY  
 GO TO REC-START-PLAY  
 REW-POWER OFF  
 REW-EJECT-POWER OFF  
 REW-PLAY  
 REW-TIMER REC



### Tape Return Play

The VTR will even search and start playback from the counter zero position after recording or playback.

- 1 Repeat steps 1 to 3 in the Tape Return operation.
- 2 Move cursor to "GO TO ZERO-PLAY"
- 3 Press EXECUTE.



# Timer Activated Recording



## Timer Recording on this VTR

Up to eight preselected programmes, can be set on this unit, up to one month in advance.



### Before You Begin

- Turn on the TV and adjust it to view the VTR output.
- Check to see that the clock on the Commander and the VTR shows the present time
- To operate the SLV373VP, read "VPS Function" first.

### To Turn On/Off the Warning Buzzer

It is possible to turn on or off the beep sound which this VTR will give whenever an illogical operation command is sent from the Commander.

- 1 Press MENU in the stop mode. The main MENU appears.
- 2 Move cursor with ▲ or ▼ to MODE SET.
- 3 Press EXECUTE. The MODE SET menu appears.
- 4 Move cursor with ▲ or ▼ to BAZZER. Select ON to activate and OFF to deactivate the buzzer by ◀ or ▶.
- 5 Press EXECUTE to store the setting and return to the original screen.




## Operation

Example: To record a programme broadcast from 20 00 to 20 50 on Tuesday, November 27, 1990 on programme position 8.

- 1 Press TIMER SET first, then press D until 27 appears. The day of the week, Tu (Tuesday), is automatically set.
- 2 Set the recording start hour with TURN ON H.
- 3 Set the recording start minute with TURN ON M.
- 4 Set the recording end hour and minute with TURN OFF H and M referring to step 2 and 3.
- 5 Set the programme position with the PROG +/- button. To select the recording speed LP, press REC MODE so that the LP indicator appears in the display. The TRANSMIT indicator blinks to indicate that all of the items are entered.
- 6 Point the Commander to the VTR and press TRANSMIT. With a beep sound, the VTR enters the timer recording standby mode. The PROGRAM LIST appears on the screen for a few seconds.
- 7 Press TIMER SET so that the present time appears on the LCD display. The VTR turns on, starts recording at the selected time, and turns off after recording ends.


## Timer Activated Recording



### Daily/Weekly Recording

This VTR can be preset to record the same programme each day of the week (daily recording) or the same programme on a specific day of every week.

Press D - on the Commander to change the LCD display in the order shown in the illustration instead of step 1 in the "Operation." When the desired recording mode is set and transmitted to the VTR, the corresponding indicator lights in the display window.



### To Set Other Programmes

Repeat steps 1 to 6 in "Operation" before step 7.

### To Stop Timer Recording

Press TIMER REC ON/OFF.

### To Record from Equipment Connected to EURO-AV or LINE IN 2 VIDEO/AUDIO Jacks

Press INPUT SELECT anytime in step 1 to 5 to change the indication from PROG -- to LINE L1 to LINE L2.

If a short beep sounds repeatedly when TRANSMIT is pressed. When BUZZER ON is selected in the MODE SET menu, the short beep indicates that the transmission is not received on the VTR. Press TRANSMIT again, then check the items below.


- No cassette is inserted
- An illogical setting has been made.
- Timer setting can only be performed when the VTR is in turned off, stop, or timer recording mode.
- Eight timer settings have already been made.
- The tape is at its end.

### If the tape is ejected after pressing TRANSMIT

The safety tab of the inserted cassette is removed.

**Understanding "one month"**  
This VTR sets the timer to record programmes to be broadcast between today and one day before the same date in the next month.



# Timer Activated Recording



## Checking the Timer Settings

The timer settings can be checked while the VTR is in the timer standby mode by displaying the programme list on the screen.

- 1 Press **TIMER REC ON/OFF** to turn off the **TIMER REC ON/OFF** indicator in the display window.
- 2 Turn on the VTR and press **TV/VTR** to light the VTR indicator. (Only when connection is made via EURO AV.)
- 3 Turn on the TV. Set to the programme position for VTR. If VTR-TV connection is made via the aerial sockets. Select VTR input on the TV. If VTR-TV connection is made via EURO AV.
- 4 Press **TIMER ON SCREEN**. The programme list appears.
- 5 Press **TIMER ON SCREEN** again to return to the original screen.
- 6 Press **TIMER REC ON/OFF** to return to the timer recording standby mode.



## Clearing/Correcting the Timer Setting


### Referring to the programme list

- 1 Display the programme list referring to steps 1 to 4 in "Checking the Timer Settings."
- 2 Press **TIMER REC CHECK** to call up and move cursor to the setting you want to correct or clear.
- 3 To clear the setting, press **TIMER REC CLEAR**. If there are other timer settings on the list, press **TIMER REC ON/OFF** return to the timer recording standby mode. To correct the setting, re-enter all of the items using the Commander. Refer to "Timer Activated Recording - Operation" steps 1 to 6. The VTR automatically enters the timer recording standby mode.


### Clearing the setting without the programme list

- 1 Press **TIMER REC ON/OFF**.
- 2 Press **TIMER REC CHECK** repeatedly until the desired programme appears in the display window.
- 3 Press **TIMER REC CLEAR**.
- 4 Press **TIMER REC ON/OFF** to return to the timer recording standby mode. If there are other programmes set for timer recording.

PROGRAM	LIST	VPS	DATE	ON	OFF	PROG
▶27	11	TUE	20:00	20:50	8	SP
15	12	SAT	12:00	2:15	L2	LP
3	12	MON	13:00	2:00	L1	SP
MON	SAT		23:00	23:15	6	LP
MON	FRI		8:15	8:30	1	SP
SUN	SAT		21:00	23:00	10	LP
EVERY	SAT		20:00	20:54	8	LP
27	11	TUE	10:00	--	4	SP



# Timer Activated Recording





## To Automatically Rewind the Tape After Timer Recording

- 1 Before setting the timer, press MENU.
- 2 Move cursor with ▲ or ▼ to MODE SET in the main menu.
- 3 Press EXECUTE.
- 4 Move cursor with ▲ or ▼ to TIMER REC-REW.
- 5 Press ◀ or ▶ to move the dot to ON. To cancel this setting, move the dot to OFF.
- 6 Press EXECUTE to store this setting and return to the original screen.

## Using the VTR during Timer Recording Standby Mode


- 1 Press TIMER REC ON/OFF to turn off the TIMER REC indicator.
- 2 Turn on the power of the VTR. The VTR is ready to be used.
- 3 After using the VTR, press TIMER REC ON/OFF and light the TIMER indicator to re-enter the timer recording standby mode.

—20—




## When the Timer Settings Overlap

- If the setting of two programmes overlap  
The recording of the following programme will begin automatically before the preceding programme ends.



- If the turn on time of two programmes are the same  
The VTR will record the programme with the smaller programme number or listed first on the programme list. The programme with the larger programme number or listed lower in the list will be erased.




- If the recording end time of programme 1 and the recording start time of programme 2 are the same  
The last 20 seconds of programme 1 will not be recorded because the VTR will enter the recording pause mode for programme 2 before programme 1 ends.

## Power Interruption during timer recording standby/timer recording mode

- If the power interruption lasts less than an hour, the VTR will enter the recording standby mode or resume timer recording when the power is recovered.
- If the power interruption exceeds an hour during the recording standby mode, the timer settings will be cleared. Reset the clock and re-enter the items for timer recording again. If the power interruption occurred during timer recording, the recording will stop and the VTR will be turned off.

## Timer Activated Recording



### To Store the Frequently Used Timer Settings in the Commander


The items selected for one timer recording programme will be erased from the LCD when TIMER SET is pressed, and cleared from the programme list as well when recording is over. However, the turn-on/turn-off time and the programme position of up to four programmes can be stored in the Commander to be recalled later. This enables you to quickly access the most frequently used items, especially your favorite weekly programme, since the recording date will automatically be shifted to the next week after the recording is over.

#### ■ Storing the parameters

- 1 Press **TIMER SET** and **MEMORY** to indicate **MEMORY A**.
- 2 Set all of the items for timer recording referring to "Timer Activated Recording — Operation."
- 3 Press **MEMORY** to change the indication to **B, C, or D**, and repeat step 2 for other programmes. The items set will be kept in the memory even when **TIMER SET** is pressed.

#### ■ Recalling and re-entering the items

- 1 Press **TIMER SET** and **MEMORY** to call up the desired memory indication (**A, B, C, or D**).
- 2 Make whatever changes necessary.
- 3 Press **TRANSMIT**. The VTR enters the timer recording standby mode.



### VPS (Video Programme System) Function (SLV-373VP only)

The German broadcasting system transmits VPS signals with the TV programmes which assures that your timer recording will be performed without missing any portion of it regardless of any earliness, time delay, extension, or broadcast interruption which might occur during that programme.


#### ■ Operation

- 1 Check whether VPS is transmitted with the programme to be recorded.
- 2 Press **VPS ON/OFF** so that the VPS indicator lights in the display window.
- 3 Set the timer referring to "Timer Activated Recording — Operation."

#### Notes

- The VPS button is effective only when the **TIMER REC ON/OFF** indicator is turned off.
- If the VPS signal was not received on the VTR because it was too weak or because the station failed to transmit, timer recording will be performed without the VPS function regardless of the VPS indication.
- The recording will stop when the VTR receives a VPS programme interruption code during recording, for example, when an urgent news bulletin was inserted. As soon as the interrupted programme resumes, recording will continue.

## Timer Activated Recording



### ■ VPS standby mode

The VTR will enter the standby mode for VPS recording far before the turn on time and remains in the standby mode passed the preset turn on time until the VPS signal is received to prepare for any change in the actual broadcast time.

When the VPS timer recording is set for a programme which is expected to start between 4:00 and 23:59, the VTR will enter the standby mode at 0:00 that day and will keep on waiting for the VPS signal until 4:00 of the next day.


When the VPS timer recording is set for a programme which is expected to start between 0:00 and 3:59, the VTR will enter the standby mode at 20:00 the day before the recording day and will keep on waiting for the VPS signal until 4:00 on the recording day.

#### Note


When the VTR is in the VPS standby mode, programme position numbers set for timer recording appear in the display window sequentially by few seconds.

### ■ If the actual recording time overlaps with the next timer recording programme

There may be cases when the actual broadcast time of two timer recording programmes overlap owing to the shift made by the VPS signal. In this case, the programme that was broadcast first always has priority. The recording of the second programme will begin only after the first programme is over.



## Quick Timer Recording



### What Is Quick Timer Recording?



The quick timer recording function provides a short cut to enter the timer recording mode or to use the timer to turn off the VTR after recording is over. The timer can be set to operate within 8 hours in units of 30 minutes.

### Operation

If you are recording, skip steps 1 to 3.

- 1 Press **INPUT SELECT** so that **TUNER** indicator is turned on.
- 2 Insert a cassette.
- 3 Press **QUICK TIMER**. **TIMER** indicator lights in the display window. While 0:00 and programme position number is blinking in the display window, select the desired programme number with **PROGRAM + / -**. A cassette with its safety tab removed will be ejected.
- 4 Press **QUICK TIMER** again to start recording. Press **QUICK TIMER** again to set the recording duration within 30 seconds from step 3, otherwise the power will be turned off. Each press of **QUICK TIMER** changes the indication in the display window in units of 30 minutes.
- 5 The recording duration will decrease minute by minute until 0:00 when the VTR will be automatically turned off.

## Quick Timer Recording






### Buttons operable during quick timer recording

- **TIMER REC ON/OFF** stops quick timer recording.
- **QUICK TIMER** changes the recording duration.
- **TIMER ON SCREEN** displays the programme list.
- **TIMER REC CHECK** changes the programme number in the display window.
- **COUNTER RESET** resets the counter to zero.
- **INDEX MARK** marks an index signal.
- **TV/VTR** switches the screen to another programme received on the TV.

If power interruption occurs during quick timer recording Recording will stop and the VTR will be turned off. If the power interruption lasted for less than one hour and if the power recovered within the quick timer duration, recording will resume from that instant.

If the unit is in timer recording standby mode Press **TIMER REC ON/OFF** to turn off the indicator, then follow steps 4 and 5.

## Index Function



### Marking Index Signals

The desired position on a tape can be located easily by detecting the index signals. There are two ways in which to mark index signals: automatic and manual. When the index signal is being marked, **INDEX** flashes in the display window and the **INDEX MARK** display will appear on the screen.

#### Automatic Index mark

An index signal is automatically marked on the tape when the VTR starts recording.


#### Manual Index mark

Index signals can be marked at desired scenes. Press **INDEX MARK** to mark an index.

#### Notes


- Leave an interval of more than 2-minute interval between two index points so that the VTR can detect each **INDEX** signal accurately.
- The recorded sound will not be heard while marking an index signal. But the signal will not be erased.
- Index signals cannot be marked on a tape whose safety tab is removed or on an unrecorded portion of the tape.

# Index Function




## Playing Back from the Index Point — INDEX SCAN

- 1 Insert a cassette with index signals.
- 2 Press INDEX once. INDEX or SCAN indicator blinks alternately and 0 (zero) lights in the display window.
- 3 Press ◀ to playback from the previous programme. Press ▶ to playback from the programme ahead. The VTR will advance to the next or previous index signal. Then the VTR will play the tape for approximately 10 seconds, and then move to the next index in the selected direction. The index number changes one by one.
- 4 Press ▷ when the desired index signal is detected.



—24—





## Locating an Index — INDEX SEARCH

Direct search of the desired index point can be performed by entering the number of how many indexes ahead or behind it is from the current tape position. The VTR counts down how many more indexes should be searched for and displays the sequence in the display window. Up to 19 indexes from the present position can be searched.



- 1 Insert a cassette with index signals.
- 2 Press INDEX to show how many indexes should be counted to reach the desired scene.
- 3 Press ◀◀ if the index is behind or ▶▶ if the index is ahead of the current tape position. The VTR starts searching and the index number will be counted down to zero.

Playback from the desired point starts.





## Index Function




### Erasing an Index

The index marked on the tape can be erased.

- 1 Insert a cassette with index signals.
- 2 Press INDEX once.
- 3 Press ◀ or ▶ to search for the index signal.  
When the VTR detects an index signal, the VTR will play the tape for approximately 10 seconds from the index. If that is the index you want to erase, go to step 4. If that is not the index you want to erase, wait until the desired index is searched.
- 4 Press INDEX ERASE while the VTR is in step 3.  
That index signal will be erased. While the index signal is being erased, the recorded sound will not be heard, but it will not be erased. If INDEX ERASE is not pressed within the 10 seconds of playback, the VTR will return to step 3.

## Indications in the Display Window




- 1 Index number indicator
- 2 VPS indicator (SLV-373VP only)  
Appears while timer recording is performed with VPS (Video Programme System) function.
- 3 INDEX SCAN indicator  
Appears while the VTR is scanning the index point.
- 4 REC (recording) indicator  
Appears while the VTR is performing normal recording, timer recording, or performing quick timer recording.
- 5 TIMER recording indicator  
Appears while the VTR is performing timer-recording, waiting for the turn-on time of timer recording, or performing quick timer recording.
- 6 Input mode indicators
- 7 Linear time counter and turn-on time of timer recording
- 8 Day of the week indicator
- 9 VTR indicator  
Appears while viewing the playback of the VTR or a programme selected on the VTR. As long as this indicator lights in the display window, the programme selected on the TV does not appear on the screen.
- 10 Various function indicators  
AUTO TRACKING (Automatic tracking), EDIT, AFT (Automatic Fine Tuning) and AUTO (AUTO MENU display).
- 11 Tape operation indicator
- 12 Tape speed indicator
- 13 Cassette indicator
- 14 Programme position/input mode indicators
- 15 Current time, turn-off time of timer recording, and quick timer recording time.


**SECTION 2  
DISASSEMBLY**

**Note:** Follow the disassembly procedure in the numerical order given.


**2-1. UPPER CASE, FRONT PANEL ASSY**




**2-2. MF-95, MF-96 AND MF-97 BOARD**




**2-3. RP-100 BOARD**




## 2-4. BOTTOM PLATE, MA-60 BOARD




## 2-5. POWER BLOCK



## 2-6. CASSETTE COMPARTMENT ASSY AND MECHANISM DECK ASSY




## 2-7. YC-90 AND CA-42 BOARD




## 2-8. INTERNAL VIEWS

—Top Side—





—Bottom Side—




# SECTION 3 DIAGRAMS

## 3-1. CIRCUIT BOARDS LOCATION



SECTION 4  
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. FRAME SCHEMATIC DIAGRAM



4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAM

THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS. (In addition to this, the necessary note is printed in each block.)

For printed wiring boards:

- — : indicates a lead wire mounted on the component side.
- — : indicates a lead wire mounted on the printed side.
- ⊗ or ⊙ : Through hole.
- ▨ : Pattern from the side which enables seeing.
- ▩ : Pattern of the rear side.

Caution:


Pattern face side: Parts on the pattern face side seen from (Conductor Side) the pattern face are indicated.  
Parts face side: Parts on the parts face side seen from (Component Side) the parts face are indicated.

For schematic diagram:


- Caution when replacing chip parts. New parts must be attached after removal of chip. Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
- All resistors are in ohms, 1/4W (Chip resistors: 1/10W) unless otherwise noted. kΩ: 1000Ω, MΩ: 1000kΩ.
- All capacitors are in μF unless otherwise noted. pF: μF 50V or less are not indicated except for electrolytics and tantalums.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- ▭ : nonflammable resistor.
- ▩ : fusible resistor.
- : panel designation.
- △ : internal component.
- : adjustment for repair.
- : B+ line.
- - - : B- line.
- Voltagages are dc between measurement points and ground unless otherwise noted.
- Readings are taken with a color-bar signal input.
- Readings are taken with a digital multimeter (DC10MΩ).
- Voltage variations may be noted due to normal production tolerances.
- ⇒ : IN/OUT direction of B line (+, -).
- Circled numbers refer to waveforms.

When indicating parts by reference number, please include the board name.

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.



No mark : REC PB mode  
( ) : REC mode  
( ) : PB mode  
\* : Can not be me



k : REC PB mode  
 ) : REC mode  
 > : PB mode  
 : Can not be measured

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC			➡➡➡
PB	➡		➡➡➡

# HEAD AMP




YC-90 (VIDEO) SCHEMATIC DIAGRAM  
 -Ref. No. YC-90 Board: 2,000 series-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


YC-90 BOARD


D701	C-5	Q723	A-7
D705	B-7	Q801	E-1
D801	D-4	Q803	E-3
		Q804	C-4
IC701	C-8	Q805	E-4
IC702	B-6	Q806	C-3
IC801	D-3	Q807	D-4
IC802	B-1	Q808	D-5
IC850	F-2	Q809	C-1
IC860	B-3	Q810	D-1
IC861	F-6	Q813	E-4
IC862	F-9	Q850	E-1
IC863	F-4	Q851	E-1
		Q852	E-4
Q702	D-6	Q860	D-2
Q704	A-8	Q862	B-4
Q705	C-7	Q880	F-7
Q706	C-6	Q881	F-9
Q710	D-9	Q882	F-9
Q711	C-6	Q883	F-5
Q721	A-9	Q884	B-4
Q722	E-10		

YC-90 BOARD




YC-90 BOARD





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



TO  
MA-60 BOARD  
CN206  
(See page 43)


TO  
MA-60 BOARD  
CN205  
(See page 43)


	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	→	⇒	⇒⇒
PB	⇐	⇐⇐	⇐⇐⇐


MA-60 (1/2) (SERVO, SYSTEM CONTROL) SCHEMATIC DIAGRAM

-Ref. No. MA-60 Board: 3,000 series-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P







MA-60 BOARD



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC			→→
PB			

	AUDIO Signal
REC	→
PB	⇨

Ref. signal	REC	REC/PB	PB
	→	⇨	⇨

TO MA-60 BOARD (2/2) (See page 56)


MA-60 (2/2) (SERVO, SYSTEM CONTROL) SCHEMATIC DIAGRAM

-Ref. No. MA60 Board: 3,000 series-

MA-60 BOARD (2/2)

**IC801**  
VPS DATA  
DECODER


**IC802**  
VPS CONTROL



※ TU701  
BTP-2C401 : SLV-373/373VP  
BTP-2U601 : SLV-373UB  
BTP-2F301 : SLV-373F

Q710-712  
EQUALIZER

IC802 CONTROL




※ IF701  
 IFB-389 : SLV-373  
 IFB-395 : SLV-373UB  
 IFV-389A : SLV-373VP  
 IFW-327 : SLV-373F

※ R726,727  
 150k : SLV-373/373UB  
 4.7k : SLV-373F  
 NON : SLV-373VP



※ R730  
 1.9k : SLV-373/373UB/373F  
 NON : SLV-373VP

※ R731  
 10k : SLV-373/373UB  
 NON : SLV-373VP/373F




A	SW 5V
B	N.C
C	VC 45V
D	N.C
E	AFT UP
F	AFT DN
G	GND (SW)
H	SW 9V
I	UNSW 12V
J	TU AUDIO
K	N.C
L	N.C
M	TU VIDEO
N	PLL CLK
O	PLL LATCH
P	PLL DATA
Q	VH U/VL
R	N.C
S	UNSW 5V
T	N.C
U	MEM CS
V	MEM CLK
W	MEM DATA
X	GND (UNSW)

Q710-712 EQUALIZER



IC702




- ※ C713  
27P : SLV-373UB  
56P : SLV-373/373VP  
NON : SLV-373F
- ※ C716  
82P : SLV-373UB  
62P : SLV-373/373VP  
NON : SLV-373F
- ※ L705  
22µH : SLV-373UB  
33µH : SLV-373/373VP  
NON : SLV-373F
- ※ R717  
1k : SLV-373/373UB/373VP  
180 : SLV-373F
- ※ R720  
1k : SLV-373/373UB/373VP  
330 : SLV-373F
- ※ R725  
620 : SLV-373UB  
1k : SLV-373/373VP  
NON : SLV-373F

No mark : EE mode




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



A	SW 5V
B	N.C
C	VC 45V
D	N.C
E	AFT UP
F	AFT DN
G	GND (SW)
H	SW 9V
I	UNSW 12V
J	TU AUDIO
K	N.C
L	N.C
M	TU VIDEO
N	PLL CLK
O	PLL LATCH
P	PLL DATA
Q	VH U/VL
R	N.C
S	UNSW 5V
T	N.C
U	MEM CS
V	MEM CLK
W	MEM DATA
X	GND (UNSW)

TO  
MA-60 BOARD(I/2)  
(See page 45)

MA-60 BOARD



	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC			⇒⇒
PB			



	AUDIO
PB	⇒


- ※ C716  
82P : SLV-373UB  
62P : SLV-373/373VP  
NON : SLV-373F
- ※ L705  
22μH : SLV-373UB  
33μH : SLV-373/373VP  
NON : SLV-373F
- ※ R720  
1k : SLV-373/373UB/373VP  
330 : SLV-373F
- ※ R725  
620 : SLV-373UB  
1k : SLV-373/373VP  
NON : SLV-373F

No mark : EE mode

MD-40 (MECHANISM DRIVE) SCHEMATIC DIAGRAM  
 -Ref. No. MD-40 Board: 4,000 series-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P










No mark : REC PB mode

MF-95 (FUNCTION, LINE IN 2), MF-96 (FOW/RVS SWITCH), MF-97 (MODE CONTROL, INDICATOR) SCHEMATIC DIAGRAMS  
 -Ref. No. MF-95, MF-96, MF-97 Boards: 6,000 series-


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P




\* : Impossible to points.




MF-97 BOARD




MF-97 BOARD  
C005  
(See page 70)




\* : Impossible to measure the voltage at the marked points.





No mark: REC/PB mode  
 ( ): REC mode  
 ( ): PB mode




CA-42 (CTL AMP/AUDIO) SCHEMATIC DIAGRAMS



-Ref. No. CA-42 Board: 7,000 series-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

CA-42 BOARD



Q101  
BUFFER





CN214 4P 2.5 EL WH		CN215 3P 2.5 EL WH	
A HEAD (X)	1	FULL ERASE (X)	1
A HEAD (Y)	2	N.C.	2
A HEAD (Z)	3	FULL ERASE (Y)	3
A ERASE HEAD	4		

No mark : REC/PB mode  
 ( ) : REC mode  
 < > : PB mode




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



POWER SUPPLY SCHEMATIC DIAGRAM

- Ref. No. 9,000 series-

SLV-373/373UB/373VP



CN711	
1	UNREG 17V
2	MTR 12V
3	MTR 12V
4	GND (MTR)
5	GND (MTR)
6	UN SW 12V
7	SW 9V
8	UN SW 5.8V
9	SW 5V
10	GND (SW)
11	GND (SW)
12	GND (AU)
13	GND (UNSW)
14	GND (UNSW)
15	+45V
16	DC 0V
17	DC 3.6V
18	-30V
19	POWER ON


TO MA-60 BOARD(U2) CN20 (See page 46)

# SLV-373/373UB/373VP


## SECTION 5 EXPLODED VIEWS

### 4-3. SEMICONDUCTOR LEAD LAYOUTS


BA4560  
CXL5003P  
LM393N  
MSM6989RS  
ST93C46AB1




AN3592K




LVA519S




PS6002




RD5.1ES-B2  
RD6.8ES-B2  
RD8.2ES-B2  
RD13ES-B2  
RD33ES-B2  
1SR139-100  
1SS119




BA10324  
LM324N  
MC14066BCP  
SDA5642



HA118016NT  
HA118019NT  
LC6543H-4374



BA7007




2SK105A-10




SLR-34MC3




TC4052BPHB



AN3231K




CXP50116-VSX350




2SA922S-QR




DTA114ES  
DTA124ES  
DTA144ES  
DTC114ES  
DTC144ES  
2SC1740S-QR  
2SD1292




AN3814K




UPD75004GB-VSX182




LA7297




PST529C  
PST529H




DTA143XS




M52435P




LA7213




M50554-182SP




CX20061



BA6238A



PT483F1




### NOTE:

- The mechanical parts with no reference number in the exploded views are not supplied.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked "\*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- Due to standardization, parts with part number suffix -XX and -X may be different from the parts specified in the components used on the set.
- Color Indication of Appearance Parts  
Example:  
(RED) ... KNOB, BALANCE (WHITE)  
↑ Cabinet's Color      ↑ Parts Color


The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.

### 5-1. FRONT PANEL, CABINET ASSEMBLIES





No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
1	1-466-315-11	SWITCH BLOCK, CONTROL (SLV-373UB)		18	*3-744-220-01	HOLDER, FL	
	1-466-315-21	SWITCH BLOCK, CONTROL (SLV-373)		19	3-741-967-01	PLATE (RIGHT), FULCRUM, DOOR	
	1-466-315-31	SWITCH BLOCK, CONTROL (SLV-373VP)		20	3-744-217-01	KNOB, SELECTION (COMMAND MODE)	
2	X-3746-001-1	PANEL ASSY, FRONT (SLV-373VP)	3-11	21	3-741-966-01	PLATE (LEFT), FULCRUM, DOOR	
	X-3746-002-1	PANEL ASSY, FRONT (SLV-373/373UB)	3-11	22	*A-6754-047-A	MF-95 BOARD, COMPLETE (SLV-373UB)	
3	3-741-971-21	BUTTON, STOP (■)		22	*A-6754-052-A	MF-95 BOARD, COMPLETE (SLV-373VP)	
4	3-741-978-21	BUTTON, STOP (■/EJECT)			*A-6754-053-A	MF-95 BOARD, COMPLETE (SLV-373)	
5	3-746-010-01	BUTTON, VPS (SLV-373VP)		23	3-741-968-01	PLATE, GROUND, MF	
6	3-741-981-31	WINDOW, LAY CATCHER BLOCK		24	*A-6721-328-A	MF-97 BOARD, COMPLETE (SLV-373UB)	
7	3-741-973-01	BUTTON, POWER (ON/STANDBY)			*A-6721-330-A	MF-97 BOARD, COMPLETE (SLV-373VP)	
8	3-741-975-01	TIP, POWER BUTTON		24	*A-6721-331-A	MF-97 BOARD, COMPLETE (SLV-373)	
9	3-741-974-01	BUTTON, EJECT (■ EJECT)		25	*3-741-992-01	STOPPER, UPPER CASE	
10	3-741-977-01	SPRING (FL), TORSION		26	X-3733-346-2	PLATE ASSY, BOTTOM	27-29
11	3-746-028-01	DOOR (E), CASSETTE		27	3-670-155-11	LEG	
12	9-911-841-XX	CUSHION (B)		28	X-3733-345-1	INSULATOR ASSY	
13	3-741-951-21	BUTTON, PLAY (▷ PLAY)		29	3-721-343-01	SCREW, FIXED, M4X7	
14	3-741-952-01	RING, SHUTTLE		30	3-746-051-01	CASE, UPPER	
15	*1-635-173-11	MF-96 BOARD		31	3-710-901-11	SCREW (3X8), TAPPING	
16	*3-741-965-01	HOLDER, PC BOARD		32	1-465-514-11	REMOTE COMMANDER ASSY (RMT-V373)	33
17	1-519-580-11	INDICATOR TUBE, FLUORESCENT		33	3-746-029-01	COVER, BATTERY	


## 5-2. CHASSIS ASSEMBLY



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
51	*A-6727-189-A	RP-100 BOARD, COMPLETE		60	*A-6725-799-A	MA-60 BOARD, COMPLETE (SLV-373UB)	
52	X-3746-004-1	GROUND ASSY, SHAFT			*A-6725-801-A	MA-60 BOARD, COMPLETE (SLV-373VP)	
53	△ 1-413-535-11	BLOCK, POWER (SLV-373UB)			*A-6725-802-A	MA-60 BOARD, COMPLETE (SLV-373)	
	△ 1-413-537-11	BLOCK, POWER (SLV-373VP)		61	1-465-260-11	TUNER, ET (BTP-2C401) (SLV-373/373VP)	
	△ 1-413-538-11	BLOCK, POWER (SLV-373)			1-465-262-11	TUNER, ET (SLV-373UB)	
54	3-746-011-01	PLATE, ORNAMENTAL, JACK		62	△ 1-466-328-11	MODULATOR, RF (RFU-2017) (SLV-373/373VP)	
55	*3-741-963-01	BRACKET, RF			△ 1-466-347-11	MODULATOR, RF (RFU-2024) (SLV-373UB)	
56	*A-6727-187-A	YC-90 BOARD, COMPLETE		63	1-558-924-41	CABLE, PIN	
57	3-736-704-01	HINGE, PC BOARD		64	*A-6713-386-A	CA-42 BOARD, COMPLETE	
58	9-911-843-XX	CUSHION		65	*3-741-962-01	PLATE, GROUND, JMP	
59	*3-746-001-01	LABEL, MODEL NUMBER (NO.2) (SLV-373UB)		66	3-741-953-03	ESCUTCHEON, FRAME	
	*3-746-002-01	LABEL, MODEL NUMBER (NO.2) (SLV-373)		67	3-741-948-11	SCREW (3), SPECIAL (+) TAPPING	
	*3-746-003-01	LABEL, MODEL NUMBER (NO.2) (SLV-373VP)		68	3-682-057-11	SPACER (SMALL)	
				69	*3-741-990-01	FRAME, MOLD	


Note: The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

### 5-3. FL CASSETTE COMPARTMENT




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
101	A-6751-421-A	FL BLOCK ASSY (M2)	102-110	106	3-736-164-01	WHEEL (FL), WORM	
102	3-716-144-02	RETAINER, WORM		107	3-736-100-01	GEAR (FL), WORM	
103	3-736-163-01	LEVER, ERASING PROTECTION		108	X-3727-784-1	MOTOR ASSY (LOADING) (M904)	
104	X-3727-775-2	GEAR (RIGHT) ASSY, MIDWAY		109	3-696-388-01	RUBBER, JOINT	
105	3-696-510-01	WASHER (3), STOPPER		110	3-739-687-01	SPRING, TENSION	

5-4. MECHANISM DECK 1



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
151	3-701-438-11	WASHER, 2.5		163	X-3729-911-1	ARM ASSY, RVS	
152	X-3727-776-1	ARM ASSY, PENDULUM		164	3-736-740-01	NUT (M2X0.25), NYLON	
153	3-669-595-00	WASHER (2), STOPPER		165	3-736-116-01	GEAR, COMMUNICATION	
154	3-736-172-02	RELEASE, LOCK, REEL		166	X-3727-770-1	PINCH ROLLER BLOCK ASSY	
155	X-3727-795-1	GEAR ASSY, RELAY		167	3-736-111-01	STOPPER	
156	3-736-074-01	RETAINER (SMALL), THRUST		168	3-736-136-01	CAM, ELEVATOR	
157	3-736-037-01	GEAR, REW		169	3-736-135-01	GEAR, PRESS CAM	
158	X-3727-798-1	TABLE ASSY, REEL		170	3-736-109-01	PLATE, OPEN, LID	
159	*A-6773-084-A	MD BLOCK ASSY 151-157,160-172,175,176 201-203,205-208,216,218,219,226-230 235,237,251-260,262,267-277,280-285 287-289,291,292,297		171	3-738-250-01	SCREW, AC ADJUSTMENT	
160	X-3733-335-1	BRAKE ASSY (AT), T SOFT		172	3-736-020-11	SPRING, COMPRESSION	
161	3-736-105-01	ARM, REV BRAKE		173	3-736-024-01	SPRING, TENSION	
162	3-736-143-01	GEAR, RVS CAM		174	3-736-025-01	SPRING (REV BRAKE), TENSION	
				175	3-744-227-01	SPRING (ATOM), FL GROUND	
				176	3-736-069-01	RETAINER, SPRING	

5-5. MECHANISM DECK 2




No.	Part No.	Description	Remark
201	A-6759-483-A	TAKE-UP BLOCK ASSY (AT), S	
202	3-736-075-01	BRAKE, S SOFT	
203	3-738-212-21	RETAINER, THRUST, REEL TABLE	
204	X-3729-935-3	TABLE ASSY, REEL, SUPPLY	
205	3-733-389-11	SPRING, TENSION	
206	X-3727-797-1	BAND ASSY, TENSION REGULATOR	
207	X-3727-786-1	SHUTTLE (LEFT) ASSY	
208	X-3733-301-1	ROLLER ASSY, GUIDE	
209	X-3727-767-1	BASE ASSY, STABILIZER	
210	1-543-647-11	HEAD, FE	
211	3-736-082-01	RETAINER, TS THRUST	
212	3-741-925-01	RING, RETAINING	
213	X-3727-771-1	STABILIZER ASSY, TAPE	
214	△ 8-848-537-11	DRUM ASSY (DZH-21A-R) (M901)	234, 236
215	3-736-047-01	SPRING (S SOFT), TENSION	
216	3-736-041-01	NUT (M3), NYLON	
217	A-6761-129-A	HEAD BLOCK ASSY, ACE	
218	3-736-042-01	SPRING, TORSION	
219	3-736-151-11	ARM (POM), TENSION REGULATOR	

No.	Part No.	Description	Remark
220	X-3729-926-1	BRAKE ASSY (2), T	221
221	3-738-220-01	SPRING (MAIN BRAKE 2), TENSION	
222	X-3733-336-2	BRAKE ASSY (2) (AT), S	221
223	3-738-221-01	SPRING (MAIN BRAKE 1), TENSION	
224	*X-3746-005-1	BASE ASSY (G), DRUM	
225	3-736-055-01	SCREW (3X8), TAPPING	
226	3-736-740-01	NUT (M2X0.25), NYLON	
227	3-736-733-01	FLANGE, 7 GUIDE	
228	3-736-730-01	SLEEVE, #7 GUIDE	
229	3-736-729-01	SPRING, COMPRESSION	
230	X-3727-787-1	SHUTTLE (RIGHT) ASSY	
231	X-3727-788-1	ROLLER ASSY, GUIDE, #2	
232	3-736-745-01	SPRING	
233	A-6747-267-C	ARM BLOCK ASSY (S), C ROLLER	
234	8-848-540-01	UPPER DRUM ASSY (DZR-21R)	
235	3-736-073-01	SLIDER, POLYETHYLENE	
236	2-643-205-01	SCREW, FITTING +PW 3X8, UPPER DRUM	
237	3-738-284-01	SPRING, TENSION	
238	*3-738-249-01	PLATE, FIXED, MD	

Note: The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

5-6. MECHANISM DECK 3



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
251	3-736-015-01	WHEEL (CAM), WORM		275	X-3727-778-1	ARM (LEFT) ASSY, THREADING	
252	3-736-158-01	PLATE, SLIDE, PENDULUM		276	3-736-142-01	ARM, TENSION REGULATOR FUNCTION	
253	A-6739-084-A	CHASSIS BLOCK ASSY, SUB	255	277	3-736-140-03	ARM, S TAKE-UP	
254	3-736-091-01	PIN, SWITCH		278	X-3733-302-1	MOTOR ASSY, CAM (M903)	295
255	3-669-465-00	WASHER (1.5), STOPPER		279	3-733-395-01	GEAR (CAM), WORM	
256	1-571-920-11	SWITCH, ROTARY (S1)		280	3-733-397-01	ARM, BRAKE FUNCTION	
257	3-669-595-00	WASHER (2), STOPPER		281	X-3733-338-1	BRAKE ASSY (AT), CAP	
258	3-736-013-01	BELT, TIMING		282	3-733-398-04	PLATE, SLIDE, BRAKE	
259	X-3727-782-1	PULLEY ASSY		283	3-736-103-03	PLATE, SLIDE, LIMITER	
260	3-736-089-01	SPRING, TENSION		284	3-736-016-01	ARM, LIMITER FUNCTION	
262	X-3727-761-1	ARM ASSY, ADJUSTMENT		285	3-736-170-01	GEAR, RKB CAM	
263	*A-6754-055-A	MD-40 BOARD, COMPLETE	264, 265, 293	286	8-835-382-01	MOTOR, DC U-26B (CAPSTAN) (M902)	
264	3-736-149-01	HOLDER, ST SENSOR		287	3-736-744-01	RETAINER, ROTOR	
265	*3-736-144-01	HOLDER, LED		288	3-733-396-01	HOLDER, CAM GEAR	
267	3-736-177-01	PLATE, SLIDE, MODE		289	3-736-176-01	GEAR, CAM	
268	3-733-394-01	GEAR, RVS RELAY		291	3-736-139-03	ARM, PENDULUM FUNCTION	
269	3-736-073-01	SLIDER, POLYETHYLENE		292	3-738-237-01	SPRING (CAP BRAKE), TENSION	
270	3-736-148-01	GEAR (RIGHT), THREADING		293	8-719-974-65	DIODE GL451V (DO01)	
271	3-736-092-01	SPRING (RIGHT), TORSION		295	*1-633-460-11	CA-41 BOARD	
272	X-3727-777-1	ARM (RIGHT) ASSY, THREADING		296	3-741-950-01	SPRING (AT), LEAF, SC GROUND	
273	3-736-147-01	GEAR (LEFT), THREADING		297	3-733-386-01	SCREW (3X8), WASHER	
274	3-736-040-01	SPRING (LEFT), TORSION					



## SECTION 7 MECHANICAL ADJUSTMENTS

Refer to "VHS MECHANICAL ADJUSTMENT MANUAL II" separately issued for MECHANICAL ADJUSTMENTS.

### PERIODIC CHECK AND REPLACEMENT

In order to obtain the best performance from this unit and make full use of its capabilities, and to extend the life of the unit and tapes, it is recommended that the following periodic checks and maintenance be performed.

\* The following must be done after every repair regardless of how many hours the user has operated the machine.

#### CLEANING OF ROTATING HEAD DISK ASSEMBLY

- 1) Press a chamois cloth (Jig Ref. No. J-7) which has been dipped in cleaning fluid (Jig Ref. No. J-5) lightly against the rotating drum assembly, then do the cleaning by slowly rotating the rotating head disk by hand. (Never try to clean by using the motor to turn it.)
- 2) Never try to clean by moving the chamois cloth at a vertical angle to the head tip. There is a very great danger of damaging the head tip if this is done.

#### CLEANING OF THE TAPE MOVEMENT SYSTEM

- 1) Clean the surfaces which the tape contacts during its movement (tape guide, drum assembly surface, capstan, pinch roller, etc.) with a chamois cloth that has been dipped in cleaning fluid.

#### CLEANING THE DRIVE SYSTEM

- 1) Clean the driving parts with a cloth that has been dipped in cleaning fluid.




Fig. 1. Parts requiring cleaning

### PERIODIC CHECK ITEMS

Perform the maintenance and check listed on the table below, according to users operating hours.

Maintenance & Check		Replacement Part No.	Operating Hours (H)										Remarks
			500	1,000	1,500	2,000	2,500	3,000	3,500	4,000	4,500	5,000	
Tape Transportation System	Cleaning of tape transportation system		○	○	○	○	○	○	○	○	○	○	This cleaning must be done whenever a repair is made.
	Cleaning and degaussing of ACE ass'y	A-6761-129-A	○	○	○	○	○	○	○	○	○	○	
	Cleaning & degaussing of video disk ass'y		○	○	○	○	○	○	○	○	○	○	The life of the head varies, depending on operational conditions and method.
Driving System	Timing belt	J-736-013-01	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	This cleaning must be done whenever a repair is made.
Performance Confirmation	Abnormal sound		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust or replace the section which causes abnormal sound.
	Measurement of FWD back tension		-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to "VHS MECHANICAL ADJUSTMENT MANUAL II" item 4-1-1. Specified value: adjust to 30 to 42 g-cm (when measured with torque cassette tape)
	Confirmation of brake system		-	☆	-	☆	-	☆	-	☆	-	☆	Confirmation must be made according to section
	Confirmation of record & playback functions		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Perform the confirmation whenever repair is made.
	Measurement of forward torque		☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	Adjust to 80-170 g-cm

○ Cleaning ☆ Confirmation

**Note:** On overhaul

When overhauling the unit, replace parts as indicated in the above table.

# SLV-373/373UB/373VP

**RMT-V373**

## **SONY** **SERVICE MANUAL**

*AEP Model*  
SLV-373

*UK Model*  
SLV-373UB

*West Germany Model*  
SLV-373VP

## **SUPPLEMENT-1**

File this supplement with the service manual.



This SUPPLEMENT-1 is for the Block Diagram and Adjustments.

TABLE OF CONTENTS


<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
<b>1. DIAGRAMS</b>			<b>2. ELECTRICAL ADJUSTMENTS</b>		
1-1.	Circuit Boards Location .....	3	2-1.	Power Supply Check (MA-60 Board) .....	44
1-2.	Over All Block Diagram .....	4	2-2.	System Control Check	
1-3.	Video Block Diagram .....	8	2-2-1.	Clock Oscillation Frequency Check .....	45
1-4.	Servo Block Diagram .....	13	2-3.	Servo System Adjustment	
1-5.	System Control Block Diagram .....	16	2-3-1.	Character Position Adjustment 1 .....	45
1-6.	System Control-Video Block Interface .....	19	2-3-2.	Character Position Adjustment 2 .....	45
1-7.	System Control-Servo Peripheral Circuit Interface .....	21	2-3-3.	Switching Position Adjustment .....	46
1-8.	System Control-Mechanism Block Interface ..	23	2-4.	Video System Adjustment	
1-9.	System Control-System Control Peripheral Circuit Interface .....	25	2-4-1.	X'tal Oscillation Frequency Check .....	46
1-10.	System Control-Audio Block Interface .....	25	2-4-2.	Sync. AGC Adjustment .....	47
1-11.	System Control Microcomputer (CXP80116: IC501 on MA-60 Board) Port Functions Description .....	27	2-4-3.	CCD Level Adjustment .....	47
1-12.	Mode Control Micro Computer CXP-50116 (MF-97 Board) Port Function Description ..	30	2-4-4.	Sync. Chip Carrier Set and Deviation Adjustment .....	47
1-13.	Audio Block Diagram .....	33	2-4-5.	White Clip/Dark Clip Adjustment .....	48
1-14.	Tuner Block Diagram .....	35	2-4-6.	Recording Y Signal Level Adjustment ...	48
1-15.	Timer, Mode Control Block Diagram .....	37	2-4-7.	Recording Chroma Level Adjustment .....	48
1-16.	Power Supply Block Diagram (1/2) .....	39	2-4-8.	Playback Y Signal Level Adjustment .....	48
	Power Supply Block Diagram (2/2) .....	41	2-4-9.	PAL Jog AFC Adjustment .....	49
			2-4-10.	0.5H CCD Level Adjustment .....	49
			2-4-11.	SECAM Sync Gate Timing Adjustment .....	49
			2-4-12.	SECAM Detection Adjustment .....	49
			2-4-13.	PB Bell Filter Adjustment .....	50
			2-4-14.	REC Bell Filter Adjustment .....	50
			2-5.	Audio System Adjustment	
			2-5-1.	Normal Audio System Adjustment .....	50
			2-6.	Tuner System Adjustment	
			2-6-1.	RF AGC Adjustment .....	51
			2-7.	Mode Control System Adjustment	
			2-7-1.	Clock Adjustment .....	52
			2-8.	Parts Arrangement Diagram for Adjustments ..	53


# SECTION 1 DIAGRAMS


1-1. CIRCUIT BOARDS LOCATION








1-2. OVER ALL BLOCK DIAGRAM
















14. SERVO BLOCK DIAGRAM







1-6. SYSTEM CONTROL – VIDEO BLOCK INTERFACE

Signal Name	Pin No.	I/O	STOP/FF/REW	TAPE LOADING	TAPE UNLOADING	PB	PB-PAUSE	SLOW	x2	CUE	REVIEW	REC	REC-PAUSE	-x1	-x2
V PB	MA-60 BOARD IC501 ①	O	H	H	H	L	L	L	L	L	L	H	H	L	L
HEAD SEL	MA-60 BOARD IC501 ③	O	L	L	L	L	H	*1	H	L	L	H	H	L	L
RF SW P	MA-60 BOARD IC501 5	O	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
Q VD/V MUTE	MA-60 BOARD IC501 ⑥	O	L	L	L	*3	*4	*4	*4	*4	*4	L	L	*4	*4
EDIT	MA-60 BOARD IC501 ⑫	O	L	L	L	*5	*5	*5	*5	*5	*5	*5	L	*5	*5
AMS	MA-60 BOARD IC501 ⑰	O	L	L	L	L	L	*6	L	*7	*7	L	L	*7	*7
SP/LP	MA-60 BOARD IC501 ⑰	O	*8	*8	*8	*9	*9	*9	*9	*9	*9	*8	*8	*9	*9
LP HEAD	MA-60 BOARD IC501 ⑱	O	*8	*8	*8	*9	L	L	L	L	L	*8	*8	L	L
REC/P	MA-60 BOARD IC501 ⑲	O	L	L	L	L	L	L	L	L	L	H	L	L	L
REC	MA-60 BOARD IC501 ⑳	O	L	L	L	L	L	L	L	L	L	H	H	L	L
COMP SYNC	MA-60 BOARD IC501 ㉓	I	*10	*10	*10	*10	*10	*10	*10	*10	*10	*10	*10	*10	*10
SKEW ON	MA-60 BOARD IC501 ㉔	O	L	L	L	L	L	L	L	*11	*11	L	L	*11	*11
COLOR CONT	MA-60 BOARD IC501 ㉕	O	L	L	L	L	*12	*13	*12	*11	*11	L	L	*11	*11

- \*1. "H" when the tape stops, and "L" when it runs (for approx. 40 msec).
- \*2. Synchronized with drum rotation. 25 Hz 50% duty pulse.
- \*3. Normally "L". "H" when CTL single is not played back.
- \*4. V-cycle "H" pulse.
- \*5. Normally "L". "H" during EDIT mode.
- \*6. HI-Z when the tape runs reverse during SP mode "L" the other conditions.
- \*7. HI-Z (2.5 V) during SP mode, or "L" during LP mode.

- \*8. By SP/LP selector, "L" during SP mode, or "H" during LP mode.
- \*9. By the mode on the recorded tape, "L" when it is SP mode, or "H" when "LP" mode.
- \*10. Composite sync. signal (positive polarity).
- \*11. "H" during LP mode.
- \*12. HI-Z during LP mode.
- \*13. HI-Z when the tapes STOP during LP mode "L" the other conditions.

1-7. SYSTEM CONTROL – SERVO PERIPHERAL CIRCUIT INTERFACE

Signal Name	Pin No.	I/O	STOP	FF	REW	TAPE LOADING	TAPE UNLOADING	PB	PB-PAUSE	SLOW	× 2	CUE	REVIEW	REC	REC-PAUSE
REC CTL *1	MA-60 BOARD IC501 ①	O	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1	*1
CAP STOP	MA-60 BOARD IC501 ②	O	H	L	L	L	L	L	H	H	L	L	L	L	H
STEP PLS	MA-60 BOARD IC501 ③	O	H	H	H	H	H	H	H	*2	H	H	H	H	H
CAP V *3	MA-60 BOARD IC501 ④	I													
SW POSITION *4	MA-60 BOARD IC501 ⑤	I													
PB CTL	MA-60 BOARD IC501 ⑥	I	H	*6	*6			*1	H/L	*2	*6	*6	*6	*1	H
VD CTL	MA-60 BOARD IC501 ⑦	I	H	*6	*6			*1	H	*2	*6	*6	*6	*1	H
DRUM PG	MA-60 BOARD IC501 ⑧	I	L	L	L	*5	*5	*7	*7	*7	*7	*7	*7	*7	*7
DRUM FG	MA-60 BOARD IC501 ⑨	I	L	L	L	*5	*5	*8	*8	*8	*8	*8	*8	*8	*8
CAP FG	MA-60 BOARD IC501 ⑩	I	H/L	*6	*6	*5	*5	*6	H/L	*9	*6	*6	*6	*6	H/L
INDEX CS	MA-60 BOARD IC501 ⑪	O							*10						
CAP RVS	MA-60 BOARD IC501 ⑫	O	H	L	H	L	H	L	L	*2	L	L	H	L	L
CAP DA *14	MA-60 BOARD IC501 ⑬	O	*11	L	L	*11	*11	*12	*11	*11	*12	*12	*12	*12	*11
DRUM DA *14	MA-60 BOARD IC501 ⑭	O	*13	*13	*13	*13	*13	*13	*13	*13	*13	*13	*13	*13	*13
REC-P	MA-60 BOARD IC501 ⑮	O	L	L	L	L	L	L	L	L	L	L	L	H	L

- \*1. 25 Hz pulse.
- \*2. "L" pulse when the tape runs.
- \*3. Input terminal for capstan constant-voltage drive.  
Used in the FF/REW mode and for cassette loading/unloading.
- \*4. Input terminal for switching position adjustment.
- \*5. Indefinite cycle pulse.
- \*6. Cycle pulse proportional to a tape speed.
- \*7. 25 Hz "H" pulse.
- \*8. 300 Hz pulse.
- \*9. Tape run time pulse.
- \*10. V-cycle "L" pulse.
- \*11. "H" or "L" pulse in a cycle of approx. 2 msec.
- \*12. "H" or "L" pulse in a cycle of approx. 1.5 msec.
- \*13. "H" or "L" pulse in a cycle of approx. 3 msec.
- \*14. 3-value output of "H", "L" and HI-Z (2.5V).

1-8. SYSTEM CONTROL – MECHANISM BLOCK INTERFACE

Signal Name	Pin No.	I/O	HI-SPEED REW	EJECTED	CASSETTE LOADING	CASSETTE UNLOADING	TAPE LOADING	TAPE UNLOADING	STOP	FF	REW	PB	PB- PAUSE	SLOW	× 2	CUE	REVIEW	REC	REC PAUSE
CAM *1	MA-60 BOARD IC501 ⑱	O	L	L	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L
LOAD	MA-60 BOARD IC501 ⑲	O	L	L	H	H	L	L	L	L	L	L	L	L	L	L	L	L	L
CW/CCW	MA-60 BOARD IC501 ⑲	O			H	L	H	L											
MODE 1	MA-60 BOARD IC501 ⑲	I	H	L	L	L	H	H	L	H	H	H	L	L	H	H	H	H	H
MODE2	MA-60 BOARD IC501 ⑳	I	L	H	H	H	H	H	L	L	L	L	H	H	L	L	L	L	H
MODE 3	MA-60 BOARD IC501 ㉑	I	H	H	H	H	L	L	L	L	L	H	H	H	H	H	L	H	H
MODE 4	MA-60 BOARD IC501 ㉒	I	H	H	H	H	H	H	L	H	H	L	L	L	L	L	L	L	L
REC PRF	MA-60 BOARD IC501 ㉓	I	*2	L	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
C-UP/DOWN	MA-60 BOARD IC501 ㉔	I	L	H	H→L	H→L	L	L	L	L	L	L	L	L	L	L	L	L	L
T REEL	MA-60 BOARD IC501 ㉕	I	*3	H/L	H/L	H/L	H/L	H/L	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
S REEL	MA-60 BOARD IC501 ㉖	I	*3	H/L	H/L	H/L	*3	*3	H/L	*3	*3	*3	H/L	*3	*3	*3	*3	*3	H/L
LAMP	MA-60 BOARD IC501 ㉗	O	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4
CAP V	MA-60 BOARD IC501 ㉘	I	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6	*6
CAP STOP	MA-60 BOARD IC501 ㉙	O	L	H			L	L	H	L	L	L	H	H	L	L	L	L	H
CAP RVS	MA-60 BOARD IC501 ㉚	O	H	H			L	H	H/L	L	H	L	L	L	L	L	H	L	L
CAP DA *8	MA-60 BOARD IC501 ㉛	O																	
T SENS	MA-60 BOARD IC501 ㉜	I	*7	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7
S SENS	MA-60 BOARD IC501 ㉝	I	*7	*4	*4	*4	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7	*7

\*1. "H" when progressing to the MECHA mode.

\*2. "L" when a cassette erasure preventive finger is bent, and "H" when not bent.

\*3. Cycle pulse proportional to a reel speed.

\*4. "H" pulse in a cycle of approx. 2 msec.

\*6. Input terminal for capstant constant-voltage drive.

Used in the FF/REW mode and for cassette loading/unloading.

\*7. Normally "L", "H" pulse in a cycle of 2 msec. when tape top or tape end is detected.

\*8. 3-value output of "H", "L" and HI-Z (2.5V).

1-9. SYSTEM CONTROL – SYSTEM CONTROL PERIPHERAL CIRCUIT INTERFACE

Signal Name	Pin No.	I/O	I/O LEVEL
RESET	MA-60 BOARD IC501 ⑦	I	Normally "H". Set to "L" when a power failure is detected or power is restored.
COSMO CS	MA-60 BOARD IC501 ⑧	I	Chip select signal from the timer microcomputer (MF-97 board IC001). V-cycle "L" pulse.
SI BUS	MA-60 BOARD IC501 ⑩	I	Serial communication data from the timer microcomputer. V-cycle "L" pulse.
SO BUS	MA-60 BOARD IC501 ⑨	O	Serial communication data to the timer microcomputer. V-cycle "L" pulse.
S CLK	MA-60 BOARD IC501 ⑪	O	Serial communication clock to the timer microcomputer. V-cycle "L" pulse.
S IN 1	MA-60 BOARD IC501 ⑫	I	Serial communication data from the INDEX IC (IC502). V-cycle "L" pulse.
S OUT 1	MA-60 BOARD IC501 ⑬	O	Serial communication data to the INDEX IC. V-cycle "L" pulse.
S CLK 1	MA-60 BOARD IC501 ⑭	O	Serial communication clock to the INDEX IC. V-cycle "L" pulse.
CS INDEX	MA-60 BOARD IC501 ⑮	O	Chip select signal to the INDEX IC (IC502). V-cycle "L" pulse.

1-10. SYSTEM CONTROL – AUDIO BLOCK INTERFACE

Signal Name	Pin No.	I/O	STOP/FF/REW	TAPE LOADING	TAPE UNLOADING	PB	PB-PAUSE	SLOW	x 2	CUE	REVIEW	REC	REC PAUSE	- x 1	- x 2
NA•PB	MA-60 BOARD IC501 ⑦	O	L	L	L	H	H	H	H	H	H	L	L		
A MUTE	MA-60 BOARD IC501 ⑩	O	L	L	L	*1	H	H	H	H	H	L	L	H	H
SP/LP	MA-60 BOARD IC501 ⑩	O	*2	*2	*2	*3	*3	*3	*3	*3	*3	*2	*2	L	*3
REC/P	MA-60 BOARD IC501 ⑮	O	L	L	L	L	L	L	L	L	L	H	L	H	L

\*1. "H" when CTL signal is not played back.

\*2. By SP/LP selector, "L" during SP mode, or "H" during LP mode.

\*3. By the mode on the recorded tape, "L" when it is SP mode, or "H" when "LP" mode.

1-11. SYSTEM CONTROL MICROCOMPUTER (CXP80116: IC501 on MA-60 Board)  
PORT FUNCTIONS DESCRIPTION

Port	Pin No.	Signal	I/O	Description
PA0	2	JOG	O	L in variable speed
PA1	1	V-PB	O	L in PB mode
PA2	80	REC	O	H in REC or REC-PAUSE mode
PA3	79	REC/F	O	H during record
PA4	78	LP HEAD	O	LP head select signal
PA5	77	SP/LP	O	L in SP mode
PA6	76	A-MUTE	O	Audio mute signal
PA7	75	TV/VTR	O	TV/VTR selection
PB0	10	LINE1	O	Input control 1
PB1	9	LINE2	O	Input control 2
PB2	8	NC	O	
PB3	7	NA-PB	O	Normal audio PB
PB4	6	Q-VD/V MUTE	O	Quasi VD signal/V mute
PB5	5	RF-SWP	O	RF switching pulse
PB6	4	OSD-VD	O	Quasi VD for OSD (This is different logically from the quasi VD.)
PB7	3	HEAD-SEL	O	Head select signal
PC0	18	CAM	O	Cam select signal
PC1	17	LOAD	O	Load select signal
PC2	16	CW/CCW	O	Rotation direction set
PC3	15	CTL-INV	O	CTL inversion
PC4	14	NC	O	
PC5	13	NC	O	
PC6	12	EDIT	O	H during edit
PC7	11	REC-CTL	O	REC CTL output

Port	Pin No.	Signal	I/O	Description
PD0	26	NC	O	
PD1	25	TA-MUTE	I	Tuner audio mute signal input
PD2	24	SKEW ON	O	Picture control while SKEW
PD3	23	COLOR CONT	O	Color control while JOG
PD4	22	MODE4	I	MD encoder input (MSB) ↑ (LSB)
PD5	21	MODE3	I	
PD6	20	MODE2	I	
PD7	19	MODE1	I	
PE0	70	DEW	I	DEW sensor input
PE1	69	VD-CTL	I	CTL counter input
PE2	68	LAMP	O	End sensor lamp signal
PE3	67	CAPSTOP	O	Capstan ON/OFF
PE4	66	DRM-DA	O	Drum DA output
PE5	65	CAP-DA	O	Capstan DA output
PE6	64	CAP-RVS	O	Capstan inversion
PE7	63	CS INDEX	O	INDEX $\mu$ com chip select
PF0	47	CAP-V	I	Capstan constant voltage FB input
PF1	46	C-UP/DWN	I	Cassette UP/DOWN
PF2	45	S-REEL	I	S reel FG
PF3	44	T-REEL	I	T reel FG
PH0	30	FULL-ERASE	O	Full erase ON
PH1	29	OSD JOG	O	OSD-VD signal select
PH2	28	STEP-PLS	O	Step pulse output
PH3	27	AMS	O	AMS control



Port	Pin No.	Signal	I/O	Description
PG0	62	CAP-FG	I	Capstan FG input
PG1	61	DRM-FG	I	Drum FG input
PG2	60	DRM-PG	I	Drum PG input
PG3	59	PB-CTL	I	PB-CTL input
PG4	58	COMP-SYNC	I	Composite sync input
PG5	57	S-SENS	I	S end sensor
PG6	56	T-SENS	I	T end sensor
PG7	55	REC-PRF	I	REC-PROOF switch
AN0	51	SW-POSI	I	Switch position adjustment
AN1	50	NC	I	
AN2	49	VIDEO-RF	I	Video RF input
AN3	48	VIDEO-DOC	I	Video DOC input (Not used)
CS0	36	COSMO CS	I	Serial line for TT handshake
SI0	37	SI BUS	I	
SO0	38	SO BUS	O	
SCK0	39	S CLK	I	
CS1	40	S CS1	I	Serial line for INDEX handshake
SI1	41	S IN1	I	
SO1	42	S OUT1	O	
SCK1	43	S CLK1	O	
AVDD	54	AVDD	-	A/D converter. Positive power supply terminal
AVREF	53	AVREF	I	A/D converter. Reference voltage input
AVSS	52	AVSS	-	A/D converter. GND
VDD	72	VDD	-	Positive power supply terminal
VSS	33/73	VSS	-	GND
EXTAL	35	EXTAL	I	System clock. 16 MHz crystal
XTAL	34	XTAL	O	
PST	32	RESET	I	Reset input
MP	31	MP	I	Microprocessor mode input (L always set)
NMI	71	NMI	I	Non-maskable interruption input (H in no use)

1-12. MODE CONTROL MICRO COMPUTER (CXP50116: IC001 on MF-97 Board) PORT  
FUNCTION DESCRIPTION


Port	Pin No.	Signal	I/O	Description
VDD	34	VDD	-	Positive power supply terminal
VSS	71	VSS	-	GND
EXTAL	74	EXTAL	I	Clock input (4.194304MHz)
XTAL	72	XTAL	O	Clock output
TEX	31	TEX	I	Backup clock input (32.768 kHz)
TX	30	TX	O	Backup clock output
PA3	50	C+ DET	I	C+ DETECT input
PA2	49	DIST1	I	Destination setting port ↑ (MSB) ↓ (LSB)
PA1	48	DIST0	I	
PA0	47	H-DET	I	VIDEO H-sync DETECT input
PC3	70	CG-CS	O	OSD CS signal
PC2	69	COSMO-CS	O	COSMO CS signal
PC1	68	VPS-CS	O	VPS CS signal
PC0	67	VPS-RESET	O	VPS RESET signal
PD3	66	MEM-CLK	O	EEP-ROM clock signal
PD2	65	MEM-CS	O	EEP-ROM CHIP-SEL signal
PD1	64	POWER-ON	O	Power control (H when the power is on.)
PD0	63	COSMO-RST	O	COSMO reset signal
PE3	58	MEM-DATA	I/O	EEP-ROM data signal
PE2	57	NC	I	
PE1	56	AFT-UP	I	Tuner AFT-UP signal
PE0	55	AFT-DOWN	I	Tuner AFT-DOWN signal
PF3	54	PLL-CLK	O	FS tuner clock output
PF2	53	PLL-LATCH	O	FS tuner latch output
PF1	52	PLL-DATA	O	FS tuner data output
PF0	51	TA-MUTE	O	Tuner audio mute

Port	Pin No.	Signal	I/O	Description
PH3	80	C+ ON	O	C+ ON/OFF
PH2	79	AV CTRL	O	AV control
PH1	78	TUNER SEL	O	TUNER select
PH0	77	TV OUT SEL	O	AV output select
PY3	62	SIRCS-IN	I	Remote control input
PY2	61	POWER-FAIL	I	Service interruption detection
PY1	60	BUZZER	O	Buzzer signal
PY0	59	VH U/ $\overline{V}$ L	O	Tuner band select
AD7	42	AD7	OUTPUT	Key input reading A/D (including shuttle switch)
AD6	41	AD6		
AD5	40	AD5		
AD4	39	AD4		
AD3	38	AD3		
AD2	37	AD2		
AD1	36	AD1		
AD0	35	AD0		
T9	19	T9	OUT	FIP grid signal
T0	28	T0		
S21	18	S17	O	(Not used)
S20	17	S16	OUTPUT	FIP segment signal
S4	1	S0		
VFDP	76	VFDP	I	Power supply for FDP
VREF	75	VREF	I	Reference voltage for resetting circuit (to Vdd)

Port	Pin No.	Signal	I/O	Description
$\overline{EC}$	43		I	Event count input (Not used)
INT	29		I	Interruption from externals (Not used)
$\overline{RESET}$	32	$\overline{RESET}$	I	Reset input
$\overline{SC}$	44	SCLK	O	Serial bus clock output
SO	45	SO (from TT)	O	Serial bus SOUT
SI	46	SI (to TT)	I	Serial bus SIN

● A/D PORT ALLOCATION

- The A/D ports are allocated as shown below.





AD \ SW	Pin No.	SW0 0.00 [V]	SW1 1.21 [V]	SW2 2.06 [V]	SW3 2.92 [V]	SW4 3.70 [V]
AD0	35	RING0	VPS	TEST	R. MODE1	R. MODE2
AD1	36	RING1	-	-	-	-
AD2	37	RING2	-	-	-	-
AD3	38	FWD/RVS	PAUSE	-	-	-
AD4	39	STOP	PLAY	POWER	EJECT	-
AD5	40	REC	AUTO/MENU	TRACK (-)	POS (+)	TV/VTR
AD6	41	H. speed REW	QUICK TMR	TRACK (+)	POS (-)	-
AD7	42	-	TMR ON/OFF	INPUT SEL	EDIT	SP/LP


- KEY input signals pass through the A/D ports as shown above.
- Chattering-cancel time is 30 msec. KEY input is assumed when there are two input signals of the same voltage within 30 msec.
- Remote control modes are selected by R. MODE 1/2.

Remote control mode	VTR1	VTR2	VTR3
R. MODE1	make	brake	brake
R. MODE2	brake	make	brake


1-13. AUDIO BLOCK DIAGRAM




1-14. TUNER BLOCK DIAGRAM




1-15. TIMER, MODE CONTROL BLOCK DIAGRAM



1-16. POWER SUPPLY BLOCK DIAGRAM (1/2)





## SECTION 2 ELECTRICAL ADJUSTMENTS

During the Adjustment, See the Parts Arrangement Diagram for the Adjustments on Page 53—54.

Necessary items and indications for total adjustment of electric circuit of this machine will be described in this chapter.

**[Using Instruments]**

- 1) Color TV
- 2) Oscilloscope 1 or 2 phenomena, band 15MHz min, delay mode, as provided.
- 3) Frequency counter (min. 8 digits)
- 4) PAL pattern generator  
SECAM pattern generator (SLV-373F)
- 5) Digital voltmeter
- 6) Audio level meter
- 7) Audio generator
- 8) Attenuator
- 9) Distortion factor meter
- 10) Alignment tape  
Part Code: PAL; H7099052H (MH-2)  
SECAM; H7099053H
- 11) RF sweep signal generator

**[Connection]**

Unless otherwise specified, connect and adjust the measuring instruments as shown in the following diagram.





Fig. 2-1.

**[Set-up Adjustment]**

Video signals output by a pattern generator are used as adjustment signals when marking the electrical adjustments, and these video output signals should be within the required standard. Connect an oscilloscope CN208 pin ① (LINE IN VIDEO) on the MA-60 Board. Check that the amplitudes of video SYNC signals, picture portions, and burst signals are flat at approximately 0.3, 0.7, and 0.3 V, respectively, and the level ratio of the burst signal and "red" signal is 0.30 : 0.66 (PAL). Fig. 2-2. shows video signals (color bars) used in marking the electrical adjustment.



**[PAL Alignment Tape (MH-2)]**

	Mode	Time	Video signal	Audio signal
1	SP	10 minutes	Stair-step	6 kHz
2		5 minutes	—	3 kHz
3		10 minutes	Color bar	1 kHz
4		3 minutes	RF sweep	—




Fig. 2-3.



**[Standard Input/output level and Impedance]**

**Input/output terminal**

Video inputs LINE IN 2: phono jacks  
EUROCONNECTOR: 21-pin (pin 20)  
1Vp-p, 75ohms, unbalanced, sync negative

Audio inputs LINE IN 2: phono jacks  
47kilohms, - 7.5dBs (0dBs=0.775Vrms)  
EUROCONNECTOR: 21-pin (pins 2 and 6)  
More than 10kilohms, - 4dBs


Video outputs EUROCONNECTOR: 21-pin (pin 19)  
1Vp-p, 75ohms, unbalanced sync negative

Audio outputs EUROCONNECTOR: 21-pin (pins 1 and 3)  
Output impedance: less than 1kilohm  
- 4dBs with 10kilohms load

CONTROL S IN Minijack (1)

**[Adjusting Sequence]**

Make the electrical adjustment in the following sequence.



**2-1. POWER SUPPLY CHECK (MA-60 BOARD)**

Mode	E-E
Measurement equipment	Digital voltmeter
MTR 12V check	
Measurement point	CN210 pins ②, ③
Specified value	12.0±0.3V dc
UNREG 17V check	
Measurement point	CN210 pin ①
Specified value	17.0±0.3V dc
SWD 5V check	
Measurement point	CN210 pin ⑨
Specified value	5.2±0.1V dc
UNSWD 5.8V check	
Measurement point	CN210 pin ⑧
Specified value	5.8±0.2V dc
UNREG 45V check	
Measurement point	CN210 pin ⑮
Specified value	45.0±3.0V dc
UNREG -30V check	
Measurement point	CN210 pin ⑱
Specified value	-30.0±2.0V dc
DC 3.6V check	
Measurement point	CN210 pin ⑰
Specified value	3.6±0.2V dc
UNSW 12V check	
Measurement point	CN210 pin ⑥
Specified value	12.0±0.3V dc
SW 9V check	
Measurement point	CN210 pin ⑦
Specified value	9.0±0.0V dc

**[Checking Method]**

- 1) Confirm that each voltage satisfies its specified value.

**2-2. SYSTEM CONTROL CHECK**  
(MA-60 Board)

**2-2-1. Clock Oscillation Frequency Check**  
(MA-60 Board)

Mode	E-E
Signal	None
Measurement point	IC401 pin ⑳
Measurement equipment	Frequency counter
Specified value	17,734,475 ± 100Hz

**Note:** Connect a 10KΩ resistor to the frequency counter.

**[Checking Method]**

- 1) Confirm that the frequency at the IC401 pin ⑳ is 17,734,475 ± 100Hz.




Fig. 2-4.

**2-3. SERVO SYSTEM ADJUSTMENT**

**[Adjustment Sequence]**

- 2-3-1. Character Position Adjustment 1
- 2-3-2. Character Position Adjustment 2
- 2-3-3. Switching Position Adjustment

**2-3-1. Character Position Adjustment 1**  
(MA-60 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC401 pin ㉑
Measurement equipment	Oscilloscope
Adjustment element	RV451
Specified value	64 ± 0.5 μsec

**[Adjustment Method]**

- 1) Adjust to 64 ± 0.5 μsec.




Fig. 2-5.

**2-3-2. Character Position Adjustment 2**  
(MA-60 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC401 pin ㉕
Measurement equipment	Frequency counter
Adjustment element	CV401
Specified value	6,900 ± 200kHz

**Note 1:** Connect a 10KΩ resistor to the frequency counter.

**Note 2:** Connect the frequency counter through a probe of high input impedance (about 10MΩ) and low capacity (10pF or less).

**[Adjustment Method]**

- 1) Adjust to 6,980 ± 200 kHz with CV401.




Fig. 2-6.

**2-3-3. Switching Position Adjustment  
(MA-60 Board)**

Mode	PB
Signal	Alignment tape SP stair-step
Measurement point	CH1: CN216 pin ①⑨ (VIDEO) CH2: CN204 pin ⑦ (RFSWP)
Measurement equipment	Oscilloscope
Adjustment element	RV501
Specified value	$6.5 \pm 0.5H$ ( $410 \pm 30 \mu\text{sec}$ )

**[Adjustment Method]**

- 1) Press the tracking adjustment buttons  $\blacktriangle$  and  $\blacktriangledown$  at the same time so that the tracking condition is the center portion.  
(AUTO TRACKING indicator is turns off.)
- 2) Adjust to  $6.5 \pm 0.5H$  ( $410 \pm 30 \mu\text{sec}$ ) with RV501.




Fig. 2-7.

**2-4. VIDEO SYSTEM ADJUSTMENT**

Adjust the video system in the following sequence as a rule. The color video signal supplied from the pattern generator is used as a video input signal for video system adjustment in the recording mode.

Make sure that sync. and color burst signals meet requirements specified at set up of adjustment shown in Fig.8-1.

**[Adjustment Sequence]**

- 2-4-1. X'tal Oscillation Frequency Check
- 2-4-2. Sync. AGC Adjustment
- 2-4-3. CCD Level Adjustment
- 2-4-4. Sync. Chip Carrier Set and Deviation Adjustment
- 2-4-5. White Clip, Dark Clip Adjustment
- 2-4-6. Recording Y Signal Level Adjustment
- 2-4-7. Recording Chroma Level Adjustment
- 2-4-8. Playback Y Signal Level Adjustment
- 2-4-9. PAL Jog AFC Adjustment
- 2-4-10. 0.5H CCD Level Adjustment
- 2-4-11. SECAM Sync Gate Timing Adjustment
- 2-4-12. SECAM Detection Adjustment

**2-4-1. X'tal Oscillation Frequency Check  
(YC-90/91 Board)**

Mode	PB
Signal	Alignment tape SP color bar
Measurement point	IC702 pin ③
Measurement equipment	Frequency counter, Oscilloscope
Specified value	$13,300,857 \pm 200\text{Hz}$

**Note:** Connect the frequency counter through a probe of high input impedance (about  $10M\Omega$ ) and low capacity ( $10\text{pF}$  or less).

**[Adjustment Method]**

- 1) Confirm the frequency of IC702 pin ③  $13,300,857 \pm 200\text{Hz}$ .
- 2) At the same time confirm the level is  $400 \pm 10\text{mVp-p}$ .




Fig. 2-8.


### 2-4-2. Sync. AGC Adjustment (YC-90/91 Board)

Mode	E-E
Signal	Color bar
Measurement point	EUROCONNECTOR: 21 pin (Pin ⑱)
Measurement equipment	Oscilloscope
Adjustment element	RV701
Specified value	$1.00 \pm 0.05V_{p-p}$

#### [Adjustment Method]

1) Adjust to  $1.00 \pm 0.05V_{p-p}$  with RV701.

YC-90 BOARD:



YC-91 BOARD:




Fig. 2-9.

### 2-4-3. CCD Level Adjustment (YC-90/91 Board)

Mode	PB
Signal	Alignment tape SP color bar
Measurement point	IC701 pin ⑩
Measurement equipment	Oscilloscope
Adjustment element	RV707
Specified value	Minimum (within $150mV_{p-p}$ )

#### [Adjustment Method]

1) Adjust the level to the minimum (within  $150mV_{p-p}$ ) with RV707.




Fig. 2-10.

### 2-4-4. Sync. Chip Carrier Set and Deviation Adjustment (YC-90/91 Board)

Sync chip carrier set	
Mode	E-E
Signal	None (Note 2)
Measurement point	IC701 pin ⑳
Measurement equipment	Frequency counter
Adjustment element	RV703
Specified value	$3.80 \pm 0.05MHz$
Deviation adjustment	
Mode	REC and PB
Signal	Color bar
Measurement point	EUROCONNECTOR: 21 pin (Pin ⑱)
Measurement equipment	Oscilloscope
Adjustment element	RV702
Specified value	$1.00 \pm 0.05V_{p-p}$

Note 1: Video output terminal must be terminated at  $75\Omega$ .


Note 2: To make no signal input, insert a shorting plug into a LINE INPUT terminal.

#### [Adjustment Method]

- 1) Input the color bar signal to place the system in the E-E mode.
- 2) Make a no-signal state and select the E-E mode. (Note 2)
- 3) Connect the frequency counter to the IC701 pin ⑳ and adjust to  $3.80 \pm 0.05MHz$  with RV703.
- 4) Input the color bar signal to make recording.
- 5) Play back a recorded tape portion and check the playback Y signal level of VIDEO OUT terminal.  
Specified value:  $1.00 \pm 0.05V_{p-p}$ .
- 6) When the specified value is not met, input the color bar signal to select the E-E mode. Adjust RV702 to correct a play back Y signal level error, and then, repeat the steps 2) through 5) above.

PB Y Level

YC-90 BOARD:



YC-91 BOARD:




Fig. 2-11.

**2-4-5. White Clip, Dark Clip Adjustment (YC-90/91 Board)**

Mode	E-E
Signal	Color bar
Measurement point	IC701 pin ②
Measurement equipment	Oscilloscope
Adjustment element	White clip: RV705 Dark clip: RV704
Specified value	White clip: $185 \pm 10\%$ Dark clip: $45 \pm 10\%$

**[Adjustment Method]**

- 1) Adjust with RV705 so that the white clip level becomes to  $185 \pm 10\%$  of the white level (100%).
- 2) Adjust with RV704 so that the dark clip level becomes to  $45 \pm 10\%$  of the white level (100%).




Fig. 2-12.

**2-4-6. Recording Y Signal Level Adjustment (YC-90/91 Board)**

Mode	E-E
Signal	None
Measurement point	CN002 pin ② (RP-100 Board)
Measurement equipment	Oscilloscope
Adjusting element	RV710
Specified value	$2.2 \pm 0.1$ Vp-p

**[Adjustment Method]**

- 1) Adjust with RV710 so that the waveform on CN002 pin ② becomes  $2.2 \pm 0.1$  Vp-p.




Fig. 2-13.

**2-4-7. Recording Chroma Level Adjustment (YC-90/91 Board)**

Mode	E-E
Signal	Color bar
Measurement point	CN704 pin ④
Measurement equipment	Oscilloscope
Adjustment element	RV801
Specified value	PAL (YC-90 Board): $165 \pm 10$ mVp-p SECAM (YC-91 Board): $65 \pm 10$ mVp-p

**[Adjustment Method]**

- 1) Adjust to the specified value with RV801.




Fig. 2-14.

**2-4-8. Playback Y Signal Level Adjustment (YC-90/91 Board)**

Mode	PB
Signal	Alignment tape SP color bar
Measurement point	EUROCONNECTOR: 21 pin (Pin ⑱)
Measurement equipment	Oscilloscope
Adjustment element	RV708
Specified value	$1.00 \pm 0.05$ Vp-p

**Note:** Make this adjustment with the EDIT switch turned off.

**[Adjustment Method]**

- 1) Adjust to  $1.00 \pm 0.05$  Vp-p with RV708.




Fig. 2-15.


### 2-4-9. PAL Jog AFC Adjustment (YC-90/91 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC860 pin ⑱ and ⑳
Measurement equipment	Digital voltmeter Oscilloscope
Adjustment element	RV860
Specified value	$2.50 \pm 0.05\text{Vdc}$

#### [Adjustment Method]

- 1) Adjust with RV860 so that the voltage on IC860 pin ⑱ becomes  $2.50 \pm 0.05\text{Vdc}$ .
- 2) At the same time, confirm the waveform on IC860 pin ⑳ becomes to as following figure.

IC860 ⑱



IC860 ⑳




Fig. 2-16.


### 2-4-10. 0.5H CCD Level Adjustment (YC-90/91 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC862 pin ② and ⑦
Measurement equipment	Oscilloscope
Adjustment element	RV861
Specified value	Following

#### [Adjustment Method]

- 1) Adjust with RV861 so that the level of the waveform on IC862 pin ② becomes the same level as on pin ⑦

YC-90 BOARD:



YC-91 BOARD:




Fig. 2-17.

### 2-4-11. SECAM Sync Gate Timing Adjustment (SLV-373F) (YC-91 Board)

Mode	Playback
Signal	Color bar
Measurement point	CH1: EUROCONNECTOR: pin ⑱ CH2: CN704 pin ④
Measurement equipment	Oscilloscope
Adjustment element	T <sub>1</sub> : RV803 T <sub>2</sub> : RV804
Specified value	T <sub>1</sub> : $2.0 \pm 0.5\mu\text{sec}$ T <sub>2</sub> : $0 \pm 0.3\mu\text{sec}$

#### [Adjustment Method]

- 1) Adjust with RV803 and RV804 so that the color bar signal on VIDEO OUT terminal becomes to the specified value.




Fig. 2-18.

### 2-4-12. SECAM Detection Adjustment (SLV-373VP) (YC-90 Board)

Mode	E-E
Signal	Color bar
Measurement point	IC850 pin ⑨
Measurement equipment	Oscilloscope
Adjustment element	RV850
Specified value	$4.0 \pm 0.1\text{Vp-p}$

#### [Adjustment Method]

- 1) Adjust with RV850 so that the waveform on IC850 pin ⑨ becomes to the specified value.




Fig. 2-19.

### 2-4-13. PB Bell Filter Adjustment (YC-91 Board)

Mode	Playback
Signal	Alignment tape color bar portion (SECAM)
Measurement point	IC801 pin ⑤
Measurement equipment	Oscilloscope
Adjustment element	FL803
Specified value	Flat waveform

#### [Adjustment Method]

- 1) Adjust FL803 until the waveform is flat.




Fig. 2-20.

### 2-4-14. REC Bell Filter Adjustment (YC-91 Board)

Mode	E-E
Signal	SECAM Color bar
Measurement point	CN704 pin ④
Measurement equipment	Oscilloscope
Adjustment element	FL804
Specified value	Same level

#### [Adjustment Method]

- 1) Adjust FL804 so that the levels of CN704 pin ④ becomes the same.




Fig. 2-21.

## 2-5. AUDIO SYSTEM ADJUSTMENT

- Adjust the audio system in the SP mode, unless otherwise specified.

Use the alignment tape.

#### [Connection]




Fig. 2-22.

### 2-5-1. Normal Audio System Adjustment

- Make adjustment in the SP mode, unless otherwise specified. Use a normal VHS cassette for an adjustment tape.
- Make adjustment with the switches set to the following positions:

INPUT SELECT ..... LINE 1

#### [Adjustment Sequence]

1. ACE Head Adjustment ..... See "VHS MECHANICAL ADJUSTMENT MANUAL II".
2. E-E Output Level Check
3. Recording Bias Adjustment
4. Overall Level Characteristic and Distortion Factor Check
5. Overall S/N Check

1. ACE Head Adjustment  
See "VHS MECHANICAL ADJUSTMENT MANUAL II".

### 2. E-E Output Level Check

Mode	E-E
Signal	400Hz, -7.5dBs
Measurement point	EUROCONNECTOR: Pin ①
Measurement equipment	Audio level meter
Specified value	-7.5 ± 2dBs

#### [Confirmation Method]

- 1) Input a signal of 400Hz, -7.5 dBs to Audio Line Input (EUROCONNECTOR: Pin ⑥).
- 2) Confirm that the audio output level is -7.5 ± 2 dBs.

### 3. Recording Bias Adjustment (CA-42 Board)

Mode	REC and PB
Signal	400Hz, -30dBs 7kHz, -30dBs
Measurement point	EUROCONNECTOR: Pin ①
Measurement equipment	Audio level meter
Adjustment element	RV251
Specified value	0 ± 1dB

#### [Adjustment Method]

- 1) Supply a signal of 400Hz, -30dBs to Audio Line Input.
- 2) Connect the audio level meter to the Audio Line Output (EUROCONNECTOR: Pin ①).
- 3) Adjust the attenuator so that the audio level meter will indicate -30dBs.
- 4) Make recording in the SP mode.
- 5) Set an audio line input signal to 7kHz and make recording.
- 6) Play back a recorded portion, and measure output levels at 400Hz and 7kHz.
- 7) Confirm that the 7kHz playback output level is within a range of the 400Hz playback output level 0 ± 1dB. When it is out of this range, adjust RV251 and repeat the steps 1) through 7) above.

### 4. Overall Level Characteristic and Distortion Factor Check

Mode	REC and PB
Signal	400Hz, -7.5dBs
Measurement point	EUROCONNECTOR: Pin ①
Measurement equipment	Audio level meter and distortion factor meter
Specified value	Playback level: -7.5 ± 2dBs Distortion factor: 4% or less

#### [Confirmation Method]

- 1) Supply an audio signal of 400Hz, -7.5dBs Audio Line Input. (EUROCONNECTOR: Pin ①).
- 2) Make recording.
- 3) Play back a recorded portion.
- 4) Confirm that a playback level is -7.5 ± 2dBs.
- 5) Confirm that a distortion factor is within 4%.

### 5. Overall S/N Check

Mode	REC and PB
Signal	400Hz, -7.5dBs, and no signal
Measurement point	EUROCONNECTOR: Pin ①
Measurement equipment	Audio level meter
Specified value	35dB or more

#### [Confirmation Method]

- 1) Supply a signal of 400Hz to Audio Line Input. Adjust the attenuator so that the audio line output level will be -7.5dBs.
- 2) Make recording.
- 3) With the REC mode held, make the no-signal state. (Short an input.)
- 4) Play back a recorded portion, and confirm that there is a level difference of 35dB or more between 400Hz portion and no-signal portion (immediately after a 400Hz signal).

### 2-6. TUNER SYSTEM ADJUSTMENT

#### 2-6-1. RF AGC Adjustment (IF701 Unit/MA-60 Board)

Signal	Broadcast TV signal
Adjustment element	VR of IF701 unit (Fig. 2-23.)

#### [Adjustment Method]

- 1) Adjust the monitor TV to a maximum contrast.
- 2) Turn the VR to make snow noise visible.
- 3) Turn the VR in an opposite direction and set it to the point where the snow noise disappears.
- 4) Receive each channel and that there are no beat picture corruption snow noises due to cross modulation.

#### [Adjustment Method]

- 1) Adjust with the volume of IF701 so that the tuner AGC terminal voltage becomes to the adjustment valve.




Fig. 2-23.

### 2-7. MODE CONTROL SYSTEM ADJUSTMENT

#### 2-7-1. Clock Adjustment (MF-97 Board)

Mode	E-E
Measurement point	IC001 pin ⑥ (PWR FAIL)
Measurement equipment	Frequency counter
Adjustment element	CV001
Adjusting value	2,097,152 ± 4 Hz

Note: Connect the following two points with jumpers.


- Pin ⑥ of CN001 (BUZZER) - GND.
- Pin ③ of IC003 (RESET) - GND.

#### [Adjustment Method]


- 1) Adjust with CV001 so that the reading on the frequency counter becomes 2,097,152 ± 4 Hz.




2-8. PARTS ARRANGEMENT DIAGRAM FOR ADJUSTMENTS



CA-42 BOARD (COMPONENT SIDE)



MF-97 BOARD (COMPONENT SIDE)



YC-90/91 BOARD (COMPONENT SIDE)

